

ForeRunner® ES-3810 Configuration Manual

MANU0220-02 - Rev. A - July, 1998

Software Versions 4.13.x and 5.1.x

FORE Systems, Inc.

1000 FORE Drive Warrendale, PA 15086-7502 Phone: 724-742-4444 FAX: 724-742-7742

http://www.fore.com

Legal Notices

Copyright [©] 1995-1998 FORE Systems, Inc. All rights reserved.

U.S. Government Restricted Rights. If you are licensing the Software on behalf of the U.S. Government ("Government"), the following provisions apply to you. If the Software is supplied to the Department of Defense ("DoD"), it is classified as "Commercial Computer Software" under paragraph 252.227-7014 of the DoD Supplement to the Federal Acquisition Regulations ("DFARS") (or any successor regulations) and the Government is acquiring only the license rights granted herein (the license rights customarily provided to non-Government users). If the Software is supplied to any unit or agency of the Government other than DoD, it is classified as "Restricted Computer Software" and the Government's rights in the Software are defined in paragraph 52.227-19 of the Federal Acquisition Regulations ("FAR") (or any successor regulations) or, in the cases of NASA, in paragraph 18.52.227-86 of the NASA Supplement to the FAR (or any successor regulations).

Printed in the USA.

No part of this work covered by copyright may be reproduced in any form. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

This publication is provided by FORE Systems, Inc. "as-is" without warranty of any kind, either express or implied, including, but not limited to, the implied warranties or conditions of merchantability or fitness for a particular purpose. FORE Systems, Inc. shall not be liable for any errors or omissions which may occur in this publication, nor for incidental or consequential damages of any kind resulting from the furnishing, performance, or use of this publication.

Information published here is current or planned as of the date of publication of this document. Because we are improving and adding features to our products continuously, the information in this document is subject to change without notice.

RESTRICTED RIGHTS LEGEND. Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 (October 1988) and FAR 52.227-19 (June 1987).

The VxWorks software used in the Mini Loader is licensed from Wind River Systems, Inc., Copyright ©1984-1996.

TRADEMARKS

FORE Systems, AVA, ForeRunner, ForeThought, ForeView, and PowerHub are registered trademarks of FORE Systems, Inc. All Roads Lead To ATM, ASN, ATV, CellChain, CellPath, CellStarter, EdgeRunner, FramePlus, ForeRunnerHE, ForeRunnerLE, Intelligent Infrastructure, I2, MSC, NetPro, Networks Of Steel, StreamRunner, TNX, Universal Port, VoicePlus, and Zero Hop Routing are unregistered trademarks of FORE Systems, Inc. All other brands or product names are trademarks or registered trademarks of their respective holders.

FCC CLASS A NOTICE

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void this user's authority to operate this equipment.

NOTE: The ASX-200WG, the ASX-200BX, the ASX-1000, and the $ForeRunnerLE^{\infty}$ 155 have been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of the equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

DOC CLASS A NOTICE

This digital apparatus does not exceed Class A limits for radio noise emission for a digital device as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la class A prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des Communications du Canada.

VCCI CLASS 1 NOTICE

この装置は、第一種情報処理装置(商工業地域において使用されるべき情報処理装置)で商工業地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会(VCCI)基準に適合しております。

従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

This equipment is in the Class 1 category (Information Technology Equipment to be used in commercial and/or industrial areas) and conforms to the standards set by the Voluntary Control Council For Interference by Information Technology Equipment aimed at preventing radio interference in commercial and/or industrial areas. Consequently, when used in a residential area or in an adjacent area thereto, radio interference may be caused to radios and TV receivers, etc. Read the instructions for correct handling.

FCC REQUIREMENTS (Notice to Users of DS1 Service)

The following instructions are provided to ensure compliance with the FCC Rules, Part 68.

- This device must only be connected to the DS1 network connected behind an FCC Part 68
 registered channel service unit. Direct connection is not allowed.
- (2) Before connecting your unit, you must inform the telephone company of the following information:

Port ID	REN/SOC	FIC	USOC
NM-6/DS1C	6.0N	04DU9-BN,	RJ48C
		04DU9-DN,	
NM-2/DS1C	6.0N	04DU9-1ZN, and	RJ48C
		04DU9-1SN	

- (3) If the unit appears to be malfunctioning, it should be disconnected from the telephone lines until you learn if your equipment or the telephone line is the source of the trouble. If your equipment needs repair, it should not be reconnected until it is repaired.
- (4) If the telephone company finds that this equipment is exceeding tolerable parameters, the telephone company can temporarily disconnect service, although they will attempt to give you advance notice if possible.
- (5) Under the FCC Rules, no customer is authorized to repair this equipment. This restriction applies regardless of whether the equipment is in or out of warranty.
- (6) If the telephone company alters their equipment in a manner that will affect use of this device, they must give you advance warning so as to give you the opportunity for uninterrupted service. You will be advised of your right to file a complaint with the FCC.

CANADIAN IC CS-03 COMPLIANCE STATEMENT

NOTICE: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Industry Canada label does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

E1 AND E3 NOTICE

The E1 (NM-6/E1C and NM-2/E1C) and E3 (NM-4/E3C and NM-2/E3C) network modules that are described in this manual are approved for use in FORE Systems' host systems providing that the instructions below are strictly observed. Failure to follow these instructions invalidates the approval.

Pan European Approval - CE Marking

Pan European approval of the E1 network module was issued by BABT following assessment against CTR12. This means that it can be connected to ONP and unstructured PTO-provided private circuits with 120 Ω interfaces in all European countries, according to Telecommunications Terminal Equipment (TTE) Directive 91/263/EEC. Thus, the following CE mark applies:

C€168.X

The E1 and E3 network modules conform to safety standard EN60950 1992 following the provisions of Low Voltage Product Safety Directive 73/23/EEC and CE Marking Directive 93/68/EEC, and can be marked accordingly with the CE symbol.

The E1 and E3 network modules conform to EN55022 1994 and EN50082-1 1992 following the provisions of the EMC Directive 89/336/EEC, and can be marked accordingly with the CE symbol.

National Approvals

UK

Network Module	Connects to	Approval Number
E1	Structured and unstructured PTO-provided private circuits with 75 Ω interfaces	AA60953
E3	PTO-provided private circuits with 75 Ω interfaces	NS/4387/1/T/605954

Germany

Network Module	Connects to	Approval Number
E3	Structured PTO-provided private circuits with 75 Ω interfaces	A127535H for the ASX-1000 A127534H for the ASX-200BX or ASX-200WG

Switzerland

Network Module	Connects to	Approval Number
E1	Structured PTO-provided private circuits with 120 Ω interfaces	96.0872.J.N
E3	Structured PTO-provided private circuits with 75 Ω interfaces	96.0873.J.N

Required User Guide Statements - UK Installation

The use of auxiliary products not authorized by FORE Systems [®] in FORE Systems ATM Switches may cause the power specification to be exceeded and is a potential safety hazard.

The equipment must be installed such that with the exception of the connections to the host, clearance and creepage distances shown in the table below are maintained between the network module and any other assemblies which use or generate a voltage shown in the table below. The larger distance shown in brackets applies where the local environment within the host is subject to conductive pollution or dry non-conductive pollution which could become conductive due to condensation. Failure to maintain these minimum distances invalidates the approval.

Clearance (mm)	Creepage (mm)	Voltage Used or Generated by Host or by Network Modules
2.0	2.4 (3.8)	Up to 50 V _{rms} or V _{dc}
2.6	3.0 (4.8)	Up to 125 V _{rms} or V _{dc}
4.0	5.0 (8.0)	Up to 250 V_{rms} or V_{dc}
4.6	6.4 (10.0)	Up to 300 V _{rms} or V _{dc}

For a host or other expansion card fitted in the host, using or generating voltages greater	Above 300 V _{rms} or V _{dc}
than 300V (rms or dc), advice from a competent telecommunications engineer must be	
obtained before installation of the relevant equipment.	

NOTE: Installing the network modules in the appropriate FORE Systems hosts, according to the installation instructions provided, satisfies the requirements listed above.

The following tables show the available ports and their safety status:

NM-6/E1C and NM-2/E1C

Ports	Safety Status
E1 Ports	TNV operating at SELV
Bus Connector	SELV

NM-4/E3C and NM-2/E3C

Ports	Safety Status
E3 Ports	TNV operating at SELV
Bus Connector	SELV

CE NOTICE

Marking by the symbol **CE** indicates compliance of this system to the EMC (Electromagnetic Compatibility) directive of the European Community and compliance to the Low Voltage (Safety) Directive. Such marking is indicative that this system meets or exceeds the following technical standards:

- EN 55022 "Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment."
- EN 50082-1 "Electromagnetic compatibility Generic immunity standard Part 1: Residential, commercial, and light industry."
- IEC 1000-4-2 "Electromagnetic compatibility for industrial-process measurement and control equipment Part 2: Electrostatic discharge requirements."
- IEC 1000-4-3 "Electromagnetic compatibility for industrial-process measurement and control equipment Part 3: Radiate electromagnetic field requirements."
- IEC 1000-4-4 "Electromagnetic compatibility for industrial-process measurement and control equipment Part 4: Electrical fast transient/burst requirements."

SAFETY CERTIFICATIONS

ETL certified to meet Information Technology Equipment safety standards UL 1950, CSA 22.2 No. 950, and EN 60950.

ALPHA/BETA TEST DISCLAIMER

This ALPHA/BETA equipment has not been tested and found to comply with the emissions limits. These limits are designed to provide reasonable protection against harmful interference. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) Reorient or relocate the receiving antenna. 2) Increase the separation between the equipment and the receiver. 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. 4) Consult FORE Systems, Inc. for more help. This equipment is to be used for evaluation purposes. Changes must not be made without the prior proper approval of FORE Systems, Inc.

This device has not been approved by the Federal Communications Commission. This device is not, and may not be, offered for sale or lease, or sold or leased until the approval of the FCC has been obtained.

Preface	•	
Technic Typogra Importa Laser N	al Suppo aphical S ant Inforr lotice Precaution Modifical	aries. ort Styles in ation Indicators in ations to Equipment in ations to FORE Systems Product Cord Connection in a source i
СНАРТ	ER 1	Introduction
1.1	The Us 1.1.1 1.1.2 1.1.3 1.1.4	er Interface
СНАРТ	ER 2	System Management
2.1	Manage	e System Menu
	2.1.1	Manage System Parameters Menu
	2.1.2	2.1.2.1 Module Selection Menu
	2.1.3	Manage Software Menu.2 - 72.1.3.1Software Selection Menu.2 - 82.1.3.2Downloading a New Software Image.2 - 82.1.3.3Software Inventory View.2 - 8
CHAPT	ER 3	Interface Management
3.1	Selectin	ng an Interface
3.2	Managi 3.2.1 3.2.2	ng 10 Mbps Ethernet Interfaces
	J.Z.Z	3.2.2.1 Interface Configuration View

3.2.3	Manage Address Database Menu
	3.2.3.1 Address Database View
	3.2.3.2 Modify Address Database Menu 3 - 9
3.2.4	Viewing Interface Counters
3.2.5	Resetting Interface Counters
Managi	ing 10/100Mbps Ethernet Interfaces
3.3.1	Resetting the Interface
3.3.2	Manage Configuration Menu
	3.3.2.1 Interface Configuration View
3.3.3	Manage Address Database Menu
	3.3.3.1 Address Database View
	3.3.3.2 Modify Address Database Menu
3.3.4	Viewing Interface Counters
3.3.5	Resetting Interface Counters
Managi	ing ATM Interfaces
3.4.1	Dual ATM Uplinks
3.4.2	Manage ATM Interface Menu
	3.4.2.1 Manage SONET/SDH Configuration Menu
	3.4.2.1.1 SONET/SDH Configuration View
	3.4.2.2 Manage LANE Configuration Menu
	3.4.2.2.1 LEC Configuration View
	3.4.2.2.2 LEC VCC List
	3.4.2.2.3 LEC ARP Cache View
	3.4.2.3 Manage RFC1483 Connection
	3.4.2.3.1 View RFC1483 Connection
	3.4.2.3.2 Create RFC1483 Connection
	3.4.2.3.3 Delete RFC1483 Connection
	3.4.2.4 Manage Signaling Configuration Menu
	3.4.2.4.1 Signaling Configuration View
	3.4.2.5 Manage ILMI Configuration
	3.4.2.5.1 Disabling ILMI
	3.4.2.5.2 Enabling ILMI
	3.4.2.6 View SONET Counters
	3.4.2.7 View ATM Counters
	3.4.2.8 View AAL5 Counters
	3.4.2.9 View LANE Counters
	3.4.2.10 View LEC Counters
	3.4.2.11 View Signaling Counters
	3.2.4 3.2.5 Manag 3.3.1 3.3.2 3.3.3 3.3.4 3.3.5 Manag 3.4.1

CHAP	TER 4	VLAN Management	
4.1	Manag	je VLAN Menu4 -	- 1
	4.1.1	Modify VLAN Menu4	- 2
	4.1.2	VLAN Selection Menu	- 3
		4.1.2.1 VLAN View	
	4.1.3	VLAN Inventory View	- 4
CHAP	TER 5	UDP/IP Management	
5.1	Manag	je UDP/IP Menu	- 1
	5.1.1	Manage ARP Cache Menu5	
		5.1.1.1 ARP Cache View	
	5.1.2	Manage IP Parameters Menu5	
	5.1.3	Manage IP Routing Table Menu	
		5.1.3.1 IP Routing Table View	
	E 1 1	5.1.3.2 Modify IP Routing Entry Menu	
	5.1.4 5.1.5	ICMP Counters	
	5.1.6	UDP Counters	
	5.1.7	Ping	
	• • • • • • • • • • • • • • • • • • • •	•	
CHAP		SNMP Management	
6.1	Manag	ge SNMP Menu	- 1
	6.1.1	Manage Access Control List Menu6	
		6.1.1.1 Access Control List View and Community Selection 6	
		6.1.1.2 Client List View	
	6.1.2	Manage Trap Destination List Menu	
	040	6.1.2.1 View Trap Destination List	
	6.1.3	SNMP Counters	- /
CHAP		Spanning Tree Management	
7.1		ew7	
	7.1.1	Spanning Tree on the ES-3810	
7.2	Manag	ge Spanning Tree Menu	- 3
	7.2.1	Selecting a Spanning Tree Instance7	- 4
	7.2.2	Displaying Spanning Tree Bridge Information7	- 4
	7.2.3	Creating a Spanning Tree Instance	
	7.2.4	Modifying Spanning Tree Bridge Information	
		7.2.4.1 Associating a VLAN to a Spanning Tree Instance	
		7.2.4.2 Modifying Spanning Tree Bridge Priority	
		7.2.4.3 Modifying Spanning Tree Bridge Maximum Age	
		7.2.4.4 Modifying Spanning Tree Bridge Hello Time	
		7.2.4.5 Modifying Spanning Tree Bridge Forward Delay	I

	7.2.5	Deletin	ng a Spanning Tree Instance	- 14
	7.2.6		ying Spanning Tree Port Status	
	7.2.7		ing-on STP on Ports	
	7.2.8	Switch	ing-off STP on Ports	· 17
	7.2.9	Manag	ging Spanning Tree Port Configuration7 -	· 18
		7.2.9.1	Selecting a Spanning Tree Port 7 -	· 19
		7.2.9.2	Displaying Spanning Tree Port Information	· 20
		7.2.9.3	Toggling STP on a Port7 -	
		7.2.9.4	Enabling/Disabling Traffic Forwarding on a Port 7 -	· 22
		7.2.9.5	Modifying STP Port Priority	
		7.2.9.6	Modifying STP Port Path Cost 7 -	· 24
СНАР	TER 8	Telnet M	lanagement	
8.1	Overvi	ew		- 1
	8.1.1	Viewin	g Telnet Parameters	- 2
	8.1.2		ng/Disabling Telnet	
	8.1.3		ing the Timeout Value	
	8.1.4		g TCP Connections8	
СНАР	TER 9	MPOA N	lanagement	
9.1	MPOA	Overview		- 1
		9.1.4.1	Configuration	- 4
		9.1.4.2	Discovery	
		9.1.4.3	Target Resolution	- 4
		9.1.4.4	Connection Management	- 6
		9.1.4.5	Data Transfer	- 6
9.2	Manag		Menu	
	9.2.1		ge MPC Configuration Menu 9	
		9.2.1.1	Enabling and Disabling MPC	
		9.2.1.2	Configuration Mode	
		9.2.1.3	Enabling/Disabling MPCs on an ELAN9 -	
		9.2.1.4	Shortcut Setup Frame Count	
		9.2.1.5	Shortcut Setup Frame Time	
		9.2.1.6	Initial Retry Time	
		9.2.1.7	Retry Maximum	
	0.00	9.2.1.8	Hold Down Time	
	9.2.2		Status	
	9.2.3		ngress and Egress Caches	
	9.2.4		MPS Table	
	9.2.5		Shortcut Routes	
	9.2.6	MPCC	Counter9 -	- 23

APPENDIX A		ESM-16 Console Management Subsystem
A.1	The Ma	iin Menu
	A.1.1	View Port Configuration
	A.1.2	View Port CountersA - 3
	A.1.3	Set Port Configuration
	A.1.4	Address Database Functions
		A.1.4.1 Set Address Aging Time
		A.1.4.2 View Address Database
		A.1.4.3 Modify Address Database
	A.1.5	Save Current Settings
	A.1.6	Reset to Factory Default Settings
	A.1.7	Download New Image
	A.1.8	Initialize Port Counters
	A.1.9	Reboot
A.2	Port Ch	paracteristics
	A.2.1	Port Parameters
	A.2.2	Address Databases

Index

Preface

This manual provides users of the *ForeRunner*[®] ES-3810 Ethernet Workgroup Switch with the information to configure and manage the ES-3810. For additional configuration information, refer to the *ForeRunner*[®] *Basic Configuration Manual*. If you have questions or problems with the installation, please contact FORE Systems Technical Assistance Center (TAC). (See "Technical Support" on page ii..)

Chapter Summaries

Chapter 1 - Introduction - Provides information about the Network Management Module, the ES-3810's console interface, and logon procedures.

Chapter 2 - System Management - Provides information about viewing and configuring ES-3810 system parameters, viewing installed modules, and managing system software.

Chapter 3 - Interface Management - Provides information about the management and configuration of the ES-3810's Ethernet and ATM interfaces, describes LANE and RFC 1483 (PVC) configuration, and describes the ES-3810's various interface counters.

Chapter 4 - VLAN Management - Describes how to create, modify, and delete VLANs, including naming, port and MAC address inclusion, IGMP filtering, and protocol (LANE or RFC1483) usage.

Chapter 5 - UDP/IP Management - Describes management of the ARP cache, IP parameters, and the IP routing table, as well as how to view ICMP, IP, and UDP counters.

Chapter 6 - SNMP Management - Describes how to modify and manage the Access Control List and the Trap Destination List, and how to view SNMP counters.

Chapter 7 - Spanning Tree Management - Describes how to create, modify, and delete Spanning Tree instances on the ES-3810, how to display the Spanning Tree configuration, and how to configure Spanning Tree on individual ports.

Chapter 8 - Telnet Management - Describes how to view the current Telnet parameters, how to enable or disable Telnet on the ES-3810, and how to modify the timeout value on the switch.

Chapter 9 - MPOA Management - Describes how to view the current MPOA parameters and MPC counters, how to manage MPC, and how to control ATM addresses.

Appendix A - ESM-16 Console Management Subsystem - Provides information about local management of the ES-3810 via the ESM-16.

Technical Support

In the U.S.A., customers can reach FORE Systems' Technical Assistance Center (TAC) using any one of the following methods:

1. Select the "Support" link from FORE's World Wide Web page:

http://www.fore.com/

2. Send questions, via e-mail, to:

support@fore.com

3. Telephone questions to "support" at:

800-671-FORE (3673) or 724-742-6999

4. FAX questions to "support" at:

724-742-7900

Technical support for customers outside the United States should be handled through the local distributor or via telephone at the following number:

+1 724-742-6999

No matter which method is used to reach FORE Support, customers should be ready to provide the following:

- A support contract ID number
- The serial number of each product in question
- All relevant information describing the problem or question

Typographical Styles

Throughout this manual, specific commands to be entered by the user appear on a separate line in bold typeface. In addition, use of the Enter, or Return, key is represented as <ENTER>. The following example demonstrates this convention:

cd \usr <ENTER>

Commands, menu options, or file names that appear within the text of this manual are represented in the following style: "...the fore_install program will install this distribution"

Important Information Indicators

To call your attention to safety and otherwise important information that must be reviewed to insure correct and complete installation, as well as to avoid damage your system, FORE Systems utilizes the following *WARNING/CAUTION/NOTE* indicators.

WARNING statements contain information that is critical to the safety of the operator and/or the system. Do not proceed beyond a **WARNING** statement until the indicated conditions are fully understood or met. This information could prevent serious damage to the operator, the system, or currently loaded software. For example:

WARNING!



Hazardous voltages are present. To lessen the risk of electrical shock and danger to personal health, follow the instructions carefully.

CAUTION statements contain information that is important for proper installation/operation. **CAUTION** statements can prevent possible equipment damage or loss of data. For example:

CAUTION



You risk damaging your equipment and/or software if you do not follow these instructions.

NOTE statements contain information that has been found important enough to be called to the special attention of the operator. For example:



Steps 1, 3, and 5 are similar to the installation for the computer type above. Review the previous installation procedure before installation in your particular model.

Laser Notice

Class 1 Laser Product: This product conforms to applicable requirements of 21 CFR 1040 at the date of manufacture.

Class 1 lasers are defined as products which do not permit human access to laser radiation in excess of the accessible limits of Class 1 for applicable wavelengths and durations. These lasers are safe under reasonably foreseeable conditions of operation. Do not view beam with optical instruments.

Every ES-3810 module with a single mode fiber optic interface contains a Class 1 laser.

Safety Precautions

For your protection, observe the following safety precautions when setting up your equipment:

- Follow all warnings and instructions marked on the equipment.
- Ensure that the voltage and frequency of your power source matches the voltage and frequency inscribed on the equipment's electrical rating label.
- Never push objects of any kind through openings in the equipment. Dangerous
 voltages may be present. Conductive foreign objects could produce a short circuit
 that could cause fire, electric shock, or damage to your equipment.

Modifications to Equipment

Do not make mechanical or electrical modifications to the equipment. FORE Systems, Inc. is not responsible for regulatory compliance of a modified FORE product.

Placement of a FORE Systems Product

CAUTION



To ensure reliable operation of your FORE Systems product and to protect it from overheating, openings in the equipment must not be blocked or covered. A FORE Systems product should never be placed near a radiator or heat register.

Power Cord Connection

WARNING!



FORE Systems AC-powered products are designed to work with single-phase power systems having a grounded neutral conductor. To reduce the risk of electrical shock, do not plug FORE Systems products into any other type of power system. Contact your facilities manager or a qualified electrician if you are not sure what type of power is supplied to your building.

WARNING!



Your AC-powered FORE Systems product is shipped with a grounding type (3-wire) power cord. To reduce the risk of electric shock, always plug the cord into a grounded power outlet.

Preface

CHAPTER 1

Introduction

The system and network management capabilities of the ES-3810 are provided by the Network Management Module (NMM) and the Network Management Controller (NMC). The primary functions of the NMM/ NMC are as follows:

- Provide SNMP-based management for the ES-3810 Ethernet Workgroup switch
- Provide a management console that permits the configuration of both systemwide (e.g., IP Address, Subnet Mask) and port-specific (e.g., Sniffing Mode, Backbone Mode) parameters

The NMM/ NMC is the management vehicle for the ES-3810, whether installed with or without the ESM-16 management module. In cases where both modules are installed in a switch, the NMM/ NMC disables the management processor of the ESM-16 while allowing the 16 ports of the ESM-16 to remain active.

Some of the main functions the local management console allows the Network Administrator to perform are as follows:

- View network activity on a per port basis
- View the configuration of a particular port
- · Configure each port with unique characteristics, if necessary
- Update the ES-3810's firmware
- View/modify a port's address database entries
- Save the ES-3810's unique port settings in non-volatile storage
- Reset the ES-3810

The management console utilizes a VT-100 terminal or VT-100 terminal emulator as an interface to the end-user. The system does not allow an escape from the menus— all options must be performed from a menu selection.



The menu system operates as an autonomous subsystem of the ES-3810. If a management station is not connected to the console port, the ES-3810 still operates using either the factory default settings detailed in the *ForeRunner ES-3810 Installation and Maintenance Manual* or the last saved settings which are restored during the power up sequence.

1.1 The User Interface

The user interface to the ES-3810 is displayed on the management station (if attached) as soon as the NMM/ NMC completes its internal power-up diagnostics. It is recommended that a console always be connected when the NMM/ NMC is turned on so that any power-up errors may be detected (see the *ForeRunner ES-3810 Installation and Maintenance Manual*).



The management console uses the VT-100 line drawing set. If your terminal (or terminal emulation package) does not support this feature, some console text may appear twice.

1.1.1 Counter Updates

Certain screens in the ES-3810 console interface provide the ability to adjust how often the displayed data is updated. On counters and displays where automatic updates are supported, the following commands are available:

- + Increases the frequency with which the screen is updated to a maximum of every two seconds.
- Decreases the frequency with which the screen is updated. There is no minimum update value.
- f Freezes the screen as it appears (i.e., the screen will not be updated).
- u Unfreezes the screen (i.e., the screen will be updated at the next regular interval).
- **q** Exits the screen.

1.1.2 Logging on to the ES-3810

Upon the first successful power-up of the ES-3810, you will be prompted for a username. Enter one of the following usernames according to the access privileges you want:

public

Grants read only privileges to objects that are accessible through the ES-3810's local management console (e.g., port counters can be viewed, but port parameters can not be changed).

private

Grants read/write privileges to all managed objects that are accessible through the ES-3810's local management console.



Logging on as private requires the use of a password. The default password is fore.

Usernames and passwords can be changed from the ES-3810 console. See Chapter 6 for more information.



Only users with read-write access can change usernames and passwords.




Figure 1.1 - ES-3810 Logon Screen

Once you have gained access to the ES-3810, you can modify, add, or delete usernames and the read/write privileges associated with them.

The following ES-3810 Main Menu appears once you have entered a valid username:

```
ES-3810 Main Menu

1) Manage System
2) Manage Interface
3) Manage VLAN
4) Manage UDP/IP
5) Manage SNMP
6) Manage Spanning Tree
7) Manage Telnet
8) Manage MPOA

9) Reset Counters

10) Logoff

Flease enter selection:
```

Figure 1.2 - ES-3810 Main Menu

The items in the previous menu have the following meanings:

Manage System Displays the Manage System Menu (Chapter 2).

Manage Interface Displays the Interface Selection screen (Chapter 3).



Once the user provides an interface selection, the management console displays the Manage Interface Menu, which is specific to the type of interface selected. For information on specific modules, see Chapter 3.

Displays the Manage VLAN Menu (Chapter 4). Manage VLAN Manage UDP/IP Displays the Manage UDP/IP Menu (Chapter 5). Displays the Manage SNMP Menu (Chapter 6). Manage SNMP Manage Spanning Tree Displays the Manage Spanning Tree Menu (Chapter 7). Displays the Manage Telnet Menu (Chapter 8). Manage Telnet Displays the Manage MPOA Menu (Chapter 9). Manage MPOA **Reset Counters** Resets all counters in the entire system to 0. The SNMP sysUpTime value is also reset to 0. Logoff Returns to the logon screen.

1.1.3 Resetting Counters

To reset the counters (e.g., IP Counters, ICMP Counters, SNMP Counters, etc.) on the ES-3810, type 9 and press <ENTER> at the Main Menu. You will be prompted to confirm your choice. To reset the counters, type \mathbf{y} and press <ENTER>, to abort the command, type \mathbf{n} and press <ENTER>, or simply press <ENTER> (see Figure 1.3).



Figure 1.3 - Reset Counters Screen

1.1.4 Logging off of the ES-3810

To end a console session on the ES-3810, type 10 and press <ENTER> at the Main Menu. Logging off returns the console to the logon screen (see Figure 1.1).

CHAPTER 2

System Management

2.1 Manage System Menu

The Manage System Menu contains options that provide access to managed objects having system-wide implications. This menu is reached from the Manage System option on the Main Menu. Figure 2.1 illustrates the Manage System Menu.




Figure 2.1 - Manage System Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.

Manage System Parameters Displays the Manage System Parameters Menu.

Manage Module Displays the Module Selection screen.

Manage Software Displays the Software Selection screen.

Save Current Configuration

Saves the value of each managed object in the current configuration to persistent storage. However, some dynamic values (i.e., address database entries) will not be saved.

Restore Factory Default Configuration

Restore Last Saved Configuration

Rest

Performs a cold restart of the system.

2.1.1 Manage System Parameters Menu

Reboot System

This menu displays commands that provide access to various system-wide interface parameters, it is accessed by selecting option 1 at the Manage System Menu. Figure 2.2 illustrates the Manage System Parameters Menu.




Figure 2.2 - Manage System Parameters Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.
Return to Previous Menu	Returns to the Manage System Menu.
View System Parameters	Displays the System Parameters View screen.
Modify System Name	Queries the user for a new system name. The new system name defaults to the current system name if the user provides no input.
Modify System Contact	Queries the user for a new system contact. The new system name defaults to the current system contact if the user provides no input.
Modify System Location	Queries the user for a new system location. The new system location defaults to the current system location if the user provides no input.
Modify Maximum Address Database Age	Queries the user for a new maximum address database age value. The new maximum address database age defaults to the current maximum address database age if the user provides no input. To disable aging, enter 0 at the prompt.
Modify Initial Filtering Mode	Queries the user for a new initial filtering mode. The choices are "positive" and "negative."

2.1.1.1 View System Parameters

This view is reached through the Manage System Menu, then through the Manage System Parameters Menu. Figure 2.3 illustrates the System Parameters View screen.




Figure 2.3 - System Parameters View

2.1.2 Manage Module Menu

This menu displays commands that monitor and control the previously selected module. This menu is reached from the Main Menu through the Manage System Menu, then through the Manage Module option. After a module is selected in the Module Selection screen, this menu will appear with options for the management of the selected module. Figure 2.4 depicts the Manage Module Menu.




Figure 2.4 - Manage Module Menu

The options in the Manage Module Menu have the following meanings:

Return to Main Menu

Return to Previous Menu	Returns to the Manage System Menu.
Select Another Module	Returns to the Module Selection screen.
View Module	Displays the Module View screen for the selected module.
Reset Module	Resets the selected module

Returns to the Main Menu.

Test Module Performs an on-line diagnostic on the selected

module. When the diagnostic has completed, the selected module is reset to the last saved configuration, and the management console displays

the Module Test View screen.

View Module Inventory Displays the Module Inventory View screen.



The Module View and Module Test View screens vary depending on the selected module. For information on specific modules, see Chapter 3.

2.1.2.1 Module Selection Menu

This menu asks the user to select a module from those installed on the system. This screen is reached from the Main Menu through the Manage System Menu. Figure 2.5 illustrates the Module Selection screen.



The management console does not allow the user to select an empty slot.

lot	Туре	State	Description
1	FEM-2/TX	Enabled	
2	ATM-1/155	Enabled	OC-3/155MM ATM Backbone Interface Module
3	SSM-16/TX	Enabled	16 Port-10BaseTX Segment Switch Module
4	ESM-24	Enabled	24-port 10BaseT Ethernet Switch Module
5	NIMM	Enabled	Network Management Module
6	ATM-1/155	Enabled	OC-3/155MM ATM Backbone Interface Module
7	PS-AC	Enabled	AC 110-220V Powersupply
8	PS-AC	Enabled	AC 110-220V Powersupply
		i	<u> 1</u> 25н

Figure 2.5 - Module Selection Menu

After a valid module is entered, the Manage Module Menu is displayed.

2.1.2.2 Module Inventory View

This view is reached from the Main Menu through the Manage System Menu, then through the Manage Module Menu screen, and finally through the Module Selection, after a module has been selected (see Section 2.1.2.1 and Figure 2.5). Figure 2.6 illustrates the Module Inventory View screen.

ES-3810 Module Selection Module 2 (ATM-1/15			(ATM-1/155)		
Slot	Туре	State	Description		
1 2 3 4 5 6 7 8	ATM-1/155 SSM-16/TX ESM-24 NMM ATM-1/155	Enabled Enabled Enabled Enabled Enabled Enabled	2-port 100BaseTX Ethernet Switch Mo OC-3/155MM ATM Backbone Interface M 16 Port-10BaseTX Segment Switch Mod 24-port 10BaseT Ethernet Switch Mod Network Management Module OC-3/155MM ATM Backbone Interface M AC 110-220V Powersupply AC 110-220V Powersupply (by Slot):	fodule Hule Hule	

 $\textbf{Figure 2.6 -} \ Module \ Inventory \ View$

2.1.3 **Manage Software Menu**

This menu displays commands that monitor and control the software installed in the system. This menu is reached from the Main Menu through the Manage System Menu, then through the Manage Software option. Figure 2.7 illustrates the Manage Software Menu.




Figure 2.7 - Manage Software Menu

The items in the Manage Software Menu have the following meanings:

Return to Main Menu R	eturns to the Main Menu.
-----------------------	--------------------------

Returns to the Manage System Menu. **Return to Previous Menu**

Returns to the Software Selection screen.

Invokes the TFTP read utility to download an image containing the selected software module.

View Software Inventory Displays the Software Inventory View screen.

2 - 7

Select Another Software Module

Download Software

2.1.3.1 Software Selection Menu

This menu asks the user to select a software module from a list of the software installed in the system. This screen is reached from the Main Menu through the Manage System Menu, then through the Manage Software option. After a valid software module ID is entered, the Manage Software Menu is displayed.

2.1.3.2 Downloading a New Software Image

For information about downloading a new software image to the ES-3810, see Chapter 4 of the *ForeRunner ES-3810 Installation and Maintenance Manual*.

2.1.3.3 Software Inventory View

This view is reached through the Manage System Menu, first by selecting the Manage Software option from the Manage System Menu and then by selecting the View Software Inventory option from the Manage Software Menu.

Interface Mai

CHAPTER 3

Interface Management

This chapter details the menus used to manage the ES-3810's various interfaces. These menus are available by selecting the Manage Interface option from the ES-3810 Main Menu.

3.1 Selecting an Interface

To choose a specific interface, or group of interfaces, select the Manage Interface option from the Main Menu, then follow the guideline in the Interface Selection screen that appears (see Figure 3.1). After selecting an interface (or group of interfaces), you will be returned to the Manage Interface Menu which now displays the options available for the selected interface.

ES-3810 Interface Selection Interfaces		ces D*	(10BaseT	Ethernet)
Interface	Description			
B1 C1 - C16	100BaseTX Ethernet OC-3c MM ATM 10BaseT Ethernet 10BaseT Ethernet OC-3c MM ATM			
 A* C* D*	 All Interfaces in 2-port 100BaseTX Etherne All Interfaces in 16 Port-10BaseTX Segment All Interfaces in 24-port 10BaseT Ethernet 	Switc	n Module	
* All Ethernet Interfaces of ES3810 Please enter selection (by Interface): _				

Figure 3.1 - Interface Selection Screen

3.2 Managing 10 Mbps Ethernet Interfaces

This section explains how to view and manage the configuration of the 10Mbps Ethernet interfaces on the ESM-16 and the ESM-24. Figure 3.2 illustrates the Manage Interface Menu for the ESM-16 and ESM-24, which is reached by selecting a 10BaseT Ethernet interface from the Interface Selection menu.




Figure 3.2 - ESM Manage Interface Menu

The items in the Manage Interface menu have the following meanings:

Returns to the Main Menu.
Returns to the Interface Selection menu.
Resets the selected interface.
Displays the Manage Interface Configuration Menu for the selected interface.
Displays the Manage Address Database Menu for the selected interface.
Displays the Interface Counters screen.
Resets all counters for the selected interface.

3.2.1 Resetting the Interface

To reset the selected interface, select the Reset Interface option from the Manage Interface Menu (see Figure 3.2).

3.2.2 Manage Interface Configuration Menu



10 Mbps segment interfaces are managed the same way as those on the ESM-16 and ESM-24, except that the address database can hold 8,192 addresses and each segment switch module supports a 4K bridge table.

This menu displays commands that provide access to managed objects that monitor and control the configuration for the selected interface. This menu is reached by selecting the Manage Interface Configuration option from the Manage Interface Menu (see Figure 3.3) for the ESMs. Figure 3.3 illustrates this menu.




Figure 3.3 - ESM Manage Interface Configuration Menu

The items in the ESM Manage Interface Configuration Menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage Interface Menu.

View Configuration Displays the Interface Configuration View screen for

the selected interface.

Receiver Queries the user to determine whether or not the

interface's receiver is to be disabled or enabled.

Polarity Correction Queries the user to determine whether or not the interface automatically corrects the polarity of the

transmit and receive pairs comprising the physical

medium.

Sniffing Queries the user to determine whether or not the

interface sniffs packets. Sniffing enables the forwarding of all transmitted and received packets onto the packet bus. In addition, the interface tags sniffed packets in order that other interfaces can

forward them out of the system.

packets that have errors. If the interface is not sniffing, then this managed object has no relevance.

Multicast Promiscuous Reception	Queries the user to determine whether or not the interface promiscuously receives all multicast address packets.
Individual Promiscuous Reception	Queries the user to determine whether or not the interface promiscuously receives all individually addressed packets.
Half/Full Duplex Connection	Queries the user to determine if the interface is to provide half or full duplex connectivity.
Internal Loopback	Queries the user to determine whether or not the interface's internal loopback is to be enabled.
Work-Group/Backbone Connection	Queries the user to determine if the interface is to provide work-group or backbone connectivity.
Transmitter	Queries the user to determine whether or not the interface's transmitter is to be disabled or enabled.
Forced Transmits	Queries the user to determine whether or not the interface forces transmits when the link is not active.
Forward Sniffed Packets	Queries the user to determine whether or not the interface forwards sniffed packets out of the system.
Forward Flagged Packets	Queries the user to determine whether or not the interface forwards flagged packets out of the system.
Multicast Hash Upload	Queries the user to determine whether or not the interface accepts multicast hash upload packets.

3.2.2.1 Interface Configuration View

This view is reached by selecting the View Configuration option from the Manage Configuration Menu (see Figure 3.3) for the ESMs. Figure 3.4 illustrates the Interface Configuration View for 10Base interfaces.

Type:	SEC-10C	Full Duplex:	Disabled
MAU:	10BaseT	Loopback:	Disabled
Number:	18	Mode:	Workgroup
Link Detected:	No	Forced Transmits:	Disabled
Link Polarity:	Correct	Polarity Correction:	Disabled
Receiver:	Enabled		Enabled
Receive Buffer:	Enabled		Enabled
Sniff Segment: Blocking: Receive Errors: Multicast Promiscuous: Individual Promiscuous:	Disabled Disabled Disabled Disabled Disabled	Transmit Sniffed Packets: Transmit Blocked Packets: Transmit Flagged Packets: Multicast Hash Upload:	

Figure 3.4 - ESM Interface Configuration View

3.2.3 Manage Address Database Menu

This menu is reached from the Main Menu through the Manage Interface menu (see Figure 3.2) by selecting the Manage Address Database option. This menu displays commands that provide access to managed objects that monitor and control the address database associated with the selected interface. Figure 3.5 illustrates the Manage Address Database Menu.




Figure 3.5 - ESM Manage Address Database Menu

The items in the ESM Manage Address Database menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage Interface Menu.

View Address Database Displays the Address Database View screen for the

selected interface.

Modify Address Database Displays the list of entries in the address database

and asks the user to select one to be modified. Next, the user is asked to modify the MAC address, age,

multicast mask, and flag values for the entry.

3.2.3.1 Address Database View

This menu is reached from the Manage Interface menu (see Figure 3.2) then through the Manage Address Database Menu (see Figure 3.5) by selecting the View Address Database option. Figure 3.6 illustrates the Address Database View screen.

ES-3810	Address Database		Interface D1	(10BaseT Ethernet)
Entry	Address	Age	Multicast Mask	Flagged
1 2 3		invalid invalid	1111 1111 1111 1111 1111 1111 1111 111	
4		invalid invalid	1111 1111 1111 1111 1111 1111	
:>				
	+, -, <u>F</u> reeze, <u>U</u> nf	roomo Ouit	_	

Figure 3.6 - ESM Address Database View for Current Configuration

3.2.3.2 Modify Address Database Menu

This menu is reached from the Manage Interface menu (see Figure 3.2) then through the Manage Address Database Menu (see Figure 3.5) by selecting the Modify Address Database option. Figure 3.6 illustrates the Modify Address Database screen.

Entry	Address	Age	Multicast Mask	Flagged
1		invalid	1111 1111 1111 1111	
2		invalid	1111 1111 1111 1111	
3		invalid	1111 1111 1111 1111	
4		invalid	1111 1111 1111 1111	
Which entry do you want to modify (1-4): 1 ddress []: 00-00-00-00-01 ge [invalid]: valid lag [No]: No				

Figure 3.7 - ESM Modify Address Database Menu

3.2.4 Viewing Interface Counters

This menu is reached from the Main Menu through the Manage Interface menu (see Figure 3.2) by selecting the View Interface Counters option. Figure 3.8 illustrates the Interface Counters screen for the interfaces supported by an ESM-16 and ESM-24.




Figure 3.8 - ESM Interface Counters View

3.2.5 Resetting Interface Counters

To reset the counters of the selected interface, select the Reset Counters option from the Manage Interface Menu (see Figure 3.2).

3.3 Managing 10/100Mbps Ethernet Interfaces

This section details the menus used to manage the interfaces on the ES-3810's Fast Ethernet Modules (FEMs). Figure 3.9 illustrates the Manage Interface Menu for the FEMs.




Figure 3.9 - FEM Manage Interface Menu

The items in the FEM Manage Interface menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.
Select Another Interface	Returns to the Interface Selection menu.
Reset Interface	Resets the selected interface.
Manage Interface Configuration	Displays the Manage Interface Configuration Menu for the selected interface.
Manage Address Database	Displays the Manage Address Database Menu for the selected interface.
View Interface Counters	Displays the Interface Counters screen.
Reset Counters	Resets all counters for the selected interface.

3.3.1 Resetting the Interface

To reset the selected interface, select the Reset Interface option from the Manage Interface Menu (see Figure 3.9).

3.3.2 Manage Configuration Menu



10/100 Mbps segment interfaces are managed the same way as those on other FEMs, except that the address database can hold 8,192 addresses.

This menu displays commands that provide access to managed objects that monitor and control the configuration for the selected 10/100 Mbps interface. This menu is reached by selecting Manage Interface Configuration option from the Manage Interface Menu (see Figure 3.9). Figure 3.10 illustrates the Manage Configuration menu for 10/100 Mbps interfaces.




Figure 3.10 - FEM Manage Configuration Menu

The items in the Manage Configuration menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage Interface Menu.

View Configuration Displays the Interface Configuration View screen for

the selected interface.

Receiver Queries the user to determine whether or not the

interface's receiver is to be disabled or enabled.

interface's receiver is to be disabled of enabled.

Queries the user to determine whether or not the interface sniffs packets. Sniffing enables the forwarding of all transmitted and received packets onto the packet bus. In addition, the interface tags sniffed packets in order that other interfaces can

forward them out of the system.

Sniffing of Error Packets Queries the user to determine whether or not the

interface sniffs packets that have errors. If the interface is not sniffing, then this managed object has

no relevance.

Multicast Promiscuous Reception Queries the user to determine whether or not the

interface promiscuously receives all multicast

address packets.

Individual Promiscuous

Reception

Sniffing

Queries the user to determine whether or not the interface promiscuously receives all individually

addressed packets.

Media Configuration Displays the current state of the auto-negotiated connection. **Internal Loopback** Queries the user to determine if the interface's internal loopback is to be disabled or enabled. Work-Group/Backbone Queries the user to determine if the interface is to Connection provide work-group or backbone connectivity. **IA Domain Matching** Queries the user to determine if individual address domain matching will be enabled. Queries the user to determine whether or not the **Transmitter** interface's transmitter is to be disabled or enabled. **Forward Sniffed Packets** Queries the user to determine whether or not the interface forwards sniffed packets out of the system. **Forward Flagged Packets** Queries the user to determine whether or not the interface forwards flagged packets out of the system. Queries the user to determine whether or not the **Multicast Hash Upload** interface accepts multicast hash upload packets. Displays the values of the registers associated with **Dump ICS1890 Registers** the selected port.

3.3.2.1 Interface Configuration View

This view is reached through the Manage Interface Menu (see Figure 3.9) and then through the Manage Configuration Menu (see Figure 3.10) by selecting the View Configuration option. Figure 3.11 illustrates the Interface Configuration View for 10/100 Mbps-based interfaces.

Type: MAU: Number:	SEC-100C 100BaseTX 0	Loopback: Mode: 	Disabled Workgroup
Media Configuration: Auto	o-Negotiation	In Progress	
Link Detected:	No	VLAN Extension:	n/a
IA Domain Matching:	Disabled	Multicast Filtering:	n/a
Receiver:	Enabled	Transmitter:	Enabled
Receive Buffer:	Enabled	Transmit Buffer:	Enabled
Sniff Segment:	Disabled	Transmit Sniffed Packets:	Disabled
Receive Errors:	Disabled	Transmit Flagged Packets:	Disabled
Multicast Promiscuous:	Disabled	Multicast Hash Upload:	Disabled
Individual Promiscuous:	Disabled		

Figure 3.11 - Interface Configuration View

3.3.3 Manage Address Database Menu

This menu is reached from the Main Menu through the Manage Interface menu (see Figure 3.9) by selecting the Manage Address Database option. This menu displays commands that provide access to managed objects that monitor and control the address database associated with the selected 10/100 Mbps interface. Figure 3.12 illustrates the Manage Address Database Menu.




Figure 3.12 - Manage Address Database Menu

The items in the FEM Manage Address Database menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.
Return to Previous Menu	Returns to the Manage Interface Menu.
View Address Database	Displays the Address Database View screen for the selected interface.
Modify Address Database Entry	Displays the list of entries in the address database and asks the user to select one to be modified. Next, the user is asked to modify the MAC address, age, multicast mask, and flag values for the entry.

3.3.3.1 Address Database View

This menu is reached from the Manage Interface menu (see Figure 3.9) then through the Manage Address Database Menu (see Figure 3.12) by selecting the View Address Database option. Figure 3.13 illustrates the Address Database View screen.

s-3810	Address Database		Interface B1 (100BaseTX Ethernet
Entry	Address	Age	Multicast Mask	Flagged
1		invalid	1111 1111 1111 1111	
2		invalid	1111 1111 1111 1111	
3		invalid	1111 1111 1111 1111	
4	FE-FF-FF-FF-FF	0	0000 0000 0000 0001	No
>				

Figure 3.13 - Address Database View

3.3.3.2 Modify Address Database Menu

This menu is reached from the Manage Interface menu (see Figure 3.9) then through the Manage Address Database Menu (see Figure 3.12) by selecting the Modify Address Database option. Figure 3.14 illustrates the Address Database Entry Selection screen.

ES-3810 Modify Address Database		Interface B1 (1	LOOBaseTX Ethernet)		
Entry	Address	Age	Multicast Mask	Flagged	
1		invalid	1111 1111 1111 1111		
2		invalid	1111 1111 1111 1111		
3		invalid	1111 1111 1111 1111		
4	FE-FF-FF-FF-FF	0	0000 0000 0000 0001	No	
Which entry do you want to modify (1-4): 1					
	Address []: 00-00-00-00-01				
Age [inva	alid]: valid				
Multicast	t Mask [1111 1111 11:	l1 1111]:			
Flag [No]: No				

Figure 3.14 - Modify Address Database Menu

3.3.4 Viewing Interface Counters

This view is reached from the Main Menu through the Manage Interface menu (see Figure 3.9) by selecting the View Interface Counters option. Figure 3.15 illustrates the View Interface Counters.

Tra	nsmit Counter:	3	Re	eceive Counte:	rs
Octets:		0	Octets:		0
Packets:		0	Packets:		0
ost Packets	:	0	Lost Packets:	:	0
Broadcasts:		0	Broadcasts:		0
Multicasts:		_	Multicasts:		0
Initially Deferred:		0	Short Packet:	∃:	0
Single Collisions:		0	Long Packets:		0
Multiple Collisions: 0		_	Framing Errors:		0
		0	FCS Errors:		0
Late Collisions:		0			
Carrier Lost	:	0			
		Packet Size	Histogram		
64	65-127		256-511	512-1024	>1024
0	0	0	0	0	0

Figure 3.15 - Interface Counters View

3.3.5 Resetting Interface Counters

To reset the counters of the selected interface, select option 7 from the Manage Interface Menu.

3.4 Managing ATM Interfaces

This section details the menus used to manage the interfaces on the ES-3810's ATM interfaces.

3.4.1 Dual ATM Uplinks

The ES-3810 supports redundant ATM Uplinks. When two ATM Uplinks are installed in an ES-3810, they share the LECs created by the user. Odd-numbered LECs reside on the ATM uplink in the lower-numbered slot of the ES-3810 chassis. Even-numbered LECs reside on the ATM uplink in the higher-numbered slot in the ES-3810 chassis. For example, with ATM uplinks in slots B and C, the odd-numbered LECs reside on the uplink in slot B, and the even numbered LECs reside on the uplink in slot C. If one of the ATM uplinks fails, the ES-3810 will reconfigure the "failed" LECs on the other uplink.



An uplink "failure" is defined as uplink module failure or cut fiber.

3.4.2 Manage ATM Interface Menu

This menu displays commands that provide access to managed objects that monitor and control the selected interface. Figure 3.16 illustrates the Manage Interface Menu for ATM Uplink Modules.




Figure 3.16 - Manage Interface Menu

The items in the previous menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Select Another Interface Returns to the Interface Selection screen.

Manage SONET/SDH Displays the Manage SONET/SDH Configuration

Configuration Menu for the selected interface.

Manage LANE Configuration Displays the Manage LANE Configuration Menu for

the selected interface.

Manage RFC1483 Connection Displays the Manage RFC1483 Connection Menu.

Manage Signaling Configuration Displays the Manage Signaling Configuration Menu

for the selected interface.

Manage ILMI Configuration Displays the Manage ILMI Configuration Menu.

View SONET Counters Displays the SONET Counters screen.

View ATM Counters Displays the ATM Counters screen.

View AAL5 Counters Displays the AAL5 Counters screen.

View LANE Counters Displays the LANE Counters screen.

View LEC Counters Displays the LEC Counters screen.

View Signaling Counters Displays the Signaling Counters screen.

3.4.2.1 Manage SONET/SDH Configuration Menu

This menu displays commands that provide access to managed objects that monitor and control the SONET/SDH (Synchronous Optical NETwork / Synchronous Digital Hierarchy) configuration for the selected ATM based interface. This menu is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.17 illustrates the Manage SONET/SDH Configuration Menu.

ES-3810 Manage Configuration Menu	Interface Al (OC-3c MM Al	PM)
Return to Main Menu Return to Previous Menu		
3) View SONET/SDH Configuration		
4) Modify Framing Standard 5) Modify Loopback Type 6) Modify Tx Clock Source 7) Modify Payload Scrambling 8) Modify Empty Cell Assignment		
Please enter selection: _		

Figure 3.17 - Manage SONET/SDH Configuration Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.
Return to Previous Menu	Returns to the Manage Interface Menu.
View SONET/SDH Configuration	Displays the SONET/SDH Configuration View screen for the selected interface.
Modify Framing Standard	Queries the user to determine the SONET/SDH framing standard to use. The current product supports two standards:
	• SONET: North American defined Synchronous Optical NETwork (default)
	• SDH: ITU defined Synchronous Digital Hierarchy
Modify Loopback Type	Queries the user to determine the loopback mode to use. The choices are:
	• Line loopback
	Diagnostics loopback
	• None (default)

Modify Tx Clock Source Queries the user to determine what source for the Tx clock to use. The choices are:

• Internal (local) clock (default)

Network (loop timing)

Modify Payload Scrambling Queries the user to determine whether or not to

enable payload scrambling. The default is Enabled.

Modify Empty Cell Assignment

Queries the user to determine the cell type to assign to empty cells. The choices are:

ATM Forum UNI Unassigned Cell (default)

• ITU I.432 Idle Cell

3.4.2.1.1 SONET/SDH Configuration View

This menu is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.18 illustrates the SONET/SDH Configuration View for ATM based interfaces.

```
ES-3810 SONET Configuration

Framing Standard: SONET
Loopback Type: None
Tx Clock Source: Internal
Payload Scrambling: Enabled
Empty Cell Assignment: Unassigned
Carrier: No
Status: 0x62C
```

Figure 3.18 - SONET/SDH Configuration View

3.4.2.2 Manage LANE Configuration Menu

This menu displays commands that provide access to managed objects that monitor and control the LANE (LAN Emulation) configuration for the selected ATM interface. This menu is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.19 illustrates the Manage LANE Configuration Menu.




Figure 3.19 - Manage LANE Configuration Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.	
Return to Previous Menu	Returns to the Manage Interface Menu.	
View LEC Configuration	Displays the ELAN Selection screen and the LEC Configuration View screen for the selected ELAN.	
View LEC VCC List	Displays the ELAN Selection screen and then the LEC VCC List screen for the selected ELAN.	
View LEC ARP Cache	Displays the ELAN Selection screen and then the LEC ARP Cache screen for the selected ELAN.	
Create LEC	Queries the user for the configuration of a new LEC.	
Delete LEC	Displays the ELAN Selection screen and then asks the user if the selected LEC should be deleted.	
Flush LEC ARP Cache	Displays the list of existing ELANs and asks the user for the ELAN whose LEC ARP cache is to be deleted.	

3.4.2.2.1 LEC Configuration View

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu then through the Manage LANE Configuration Menu. The user is then asked to select an ELAN to view. Figure 3.20 illustrates the LEC Configuration View.

```
ES-3810 LEC Configuration ELAN Id: 2
ELAN Name:
                marketing
ELAN Id:
LEC Id:
                 0
Admin Status:
                Up
Operational Status: Waiting for Local Address
                0xFF
Selector:
                Mode:
LEC Address:
           LECS Address:
|LECS Address:
|LES Address:
BUS Address:
                 | Config. Direct VCI: None
| Control Direct VCI: None
Control Distribute VCI: None
Multicast Send VCI:
                 None
Multicast Forward VCI: None
Hit <Enter> to continue.
```

Figure 3.20 - LEC Configuration View

3.4.2.2.2 LEC VCC List

This screen lists all of the Virtual Channel Connections (VCCs) in use by a given LAN Emulation Client (LEC). This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu then through the Manage LANE Configuration Menu and finally through the ELAN Selection screen. Figure 3.21 illustrates the LEC VCC List screen for the selected ELAN.

ES-3810 VC List ELAN Id: 1			
ELAN Id: 1, Elan Name: default			
Index	VCI	VCI Type	
1	226	Config. Direct VCI	
2	227	Control Direct VCI	
3	228	Control Distribute VCI	
4	229	Multicast Send VCI	
5	230	Multicast Forward VCI	
6	231	Data Direct VCI	
:			
Hit <enter> to continue.</enter>			

Figure 3.21 - LEC VCC List View

3.4.2.2.3 LEC ARP Cache View

This screen lists all of the current ARP (Address Resolution Protocol) cache entries for the selected LAN Emulation Client (LEC). This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu then through the Manage LANE Configuration Menu and finally through the ELAN Selection screen. Figure 3.22 illustrates the LEC ARP Cache View screen for the selected ELAN.

Figure 3.22 - LEC ARP Cache View

3.4.2.3 Manage RFC1483 Connection

This menu displays options that let the user view, create, and delete RFC 1483 Permanent Virtual Circuits (PVCs). PVCs act like ELANs on the ES-3810, in that you can associate VLANs to PVCs. The Manage RFC1483 Connection Menu is shown in Figure 3.23.




Figure 3.23 - Manage RFC1483 Connection Menu

3.4.2.3.1 View RFC1483 Connection

The View RFC1483 Connection Menu lets the user select a PVC and view its current configuration. To select a PVC, type 2 and press <ENTER> in the Manage RFC1483 Connection Menu. When the View RFC1483 Connection Menu appears, type the number that corresponds to the desired PVC and press <ENTER> (see Figure Figure 3.24). After selecting a PVC, it's connection parameters are displayed (see Figure 3.25).

```
ES-3810 View RFC1483 Connection

2. test
4. PVC Connection
5. PVC One
6. PVC Two
7. PVC Three
```

Figure 3.24 - View RFC1483 Connection Menu

```
ES-3810 View RFC1483 Connection

RFC1483 Connection Name: marketing
Connection Id : 2
voi is 100.

Hit <Enter> to continue._
```

Figure 3.25 - View RFC1483 Connection

3.4.2.3.2 Create RFC1483 Connection

This menu lets the user create PVCs by choosing a name for the connection (ELAN) and a VCI value. To create a PVC, type 4 and press <ENTER> in the Manage RFC1483 Connection Menu. When prompted, type the name of the connection and press <ENTER>, type in the VCI value for the connection and press <ENTER>.

After entering the VCI for the connection, you are prompted to confirm the settings you just entered. If you are satisfied with the settings, type \mathbf{y} and press <ENTER>. If you are not satisfied with the settings, type \mathbf{n} and press <ENTER>. After accepting or declining your choices, press <ENTER> again (see Figure 3.26).

```
ES-3810 Create RFC1483 Connection

Configuring a new RFC1483 Connection...

Enter Connection Name: marketing
Enter VCI: 150

RFC1483 Connection Name: marketing
vci is 150.
Are you satisfied with these settings [No]? y

RFC 1483 Connection Configured. (ELAN ID: 8)
Connection Name: marketing
PVC Number: 150

Hit <Enter> to continue.__
```

Figure 3.26 - Creating a PVC

3.4.2.3.3 Delete RFC1483 Connection

This menu lets the user delete PVCs. To delete PVCs, type 5 and press <ENTER> in the Manage RFC1483 Connection Menu. When the Delete RFC1483 Connection Menu appears, type the number that corresponds to the PVC to be deleted and press <ENTER> (see Figure 3.27).

ES-3810 Delete RFC1483 Connection
2. marketing 7. testing 8. pubs 9. graphics
Which Connection: 2

Figure 3.27 - Selecting a PVC to Delete

You are asked to confirm your choice. If you still wish to delete the PVC, type \mathbf{y} and press <ENTER>. If you do not wish to delete the PVC, type \mathbf{n} and press <ENTER>. After confirming your choice, press <ENTER> (see Figure 3.28).




Figure 3.28 - Confirming the Deletion of a PVC

3.4.2.4 Manage Signaling Configuration Menu

This menu displays commands that provide access to managed objects that monitor and control the signaling configuration for the selected ATM interface. This menu is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.23 illustrates the Manage Signaling Configuration Menu.

```
ES-3810 Manage Signaling Configuration Menu Interface A1 (OC-3c MM ATM)

1) Return to Main Menu
2) Return to Previous Menu
3) View Signaling Configuration
4) Disable Signaling
5) Enable Signaling
```

Figure 3.29 - Manage Signaling Configuration Menu

The items in the previous menu have the following meanings:

in the breatens ment in a constant with the mentione of the property of the pr				
Return to Main Menu	Returns to the Main Menu.			
Return to Previous Menu	Returns to the Manage Interface Menu.			
View Signaling Configuration	Displays the Signaling Configuration View screen for the selected interface.			
Disable Signaling	Attempts to disable signaling, but asks for user confirmation before doing so.			
Enable Signaling	Attempts to enable signaling, but asks for user confirmation before doing so.			

3.4.2.4.1 Signaling Configuration View

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu and then through the Manage Signaling Configuration Menu. Figure 3.24 illustrates the Signaling Configuration View.

```
ES-3810 Signaling Configuration

ILMI Mode: Up
ATM Network Prefix: 0x00.0000.00000.0000.0000.0000
End System ID (ESI): 00-A0-36-00-05-61
```

Figure 3.30 - Signaling Configuration View

3.4.2.5 Manage ILMI Configuration

This menu lets the user manage ILMI on the ATM interface of the ES-3810. To manage ILMI, type 7 and press <ENTER> in the Manage Interface Menu. The Manage ILMI Configuration Menu appears (see Figure 3.31).




Figure 3.31 - Manage ILMI Configuration Menu

3.4.2.5.1 Disabling ILMI

To disable ILMI on the selected ATM interface, type 3 and press <ENTER> in the Manage ILMI Configuration Menu.



You can not disable ILMI until you have delete all the ELANs on the ES-3810. Delete LANE ELANs from the Manage LANE Configuration Menu. Delete PVC ELANs from the Manage RFC1483 Connection Menu.

Once you have deleted all ELANs on the ES-3810, you can disable ILMI. After entering 3 in the Manage ILMI Configuration Menu, you are prompted to confirm you choice to disable ILMI. If you still wish to disable ILMI, type \mathbf{y} and press <ENTER>. If you do not wish to disable ILMI, type \mathbf{n} and press <ENTER>. After confirming whether or not to disable ILMI, press <ENTER> again (see Figure 3.32).




Figure 3.32 - Disabling ILMI

3.4.2.5.2 Enabling ILMI

To enable ILMI on the selected ATM interface, type 4 and press <ENTER> in the Manage ILMI Configuration Menu. When prompted to confirm your choice type y and press <ENTER> if you still wish to enable ILMI. If you do not wish to enable ILMI, type n and press <ENTER>. After confirming whether or not to enable ILMI, press <ENTER> again (see Figure 3.33).

```
ES-3810 Enable ILMI

Are you sure to enable ILMI [No]? y
ILMI has been enabled.Hit <Enter> to continue.
```

Figure 3.33 - Enabling ILMI

3.4.2.6 View SONET Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.34 illustrates the SONET Counters screen for interfaces supported by an ATM module.




Figure 3.34 - SONET Counters View

3.4.2.7 View ATM Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.35 illustrates the ATM Counters screen for interfaces supported by an ATM module.




Figure 3.35 - ATM Counters View

3.4.2.8 View AAL5 Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.36 illustrates the AAL5 Counters screen for interfaces supported by an ATM module.




Figure 3.36 - AAL5 Counters View

3.4.2.9 View LANE Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.37 illustrates the LANE Counters screen for interfaces supported by an ATM module.

```
ES-3810 LANE Counters
                                                                         5:16.15
Total Bytes to ATM:
Total Bytes to Ethernet:
                                     0
                                     0
Cells to Ethernet Dropped:
                                     0
Packets to ATM Dropped:
Packets From ATM Dropped:
                                     0
Wrong Size ATM PDUs:
                                     0
                                     0
Wrong Size Ethernet Frames:
                                     Π
Echo Suppressions:
Invalid VCC Accessed:
                                     0
Limits to BUS Exceeded:
                                     0
Unrecognized Ethernet Frames:
                                     0
Commands: +, -, Freeze, Unfreeze, Quit
```

Figure 3.37 - LANE Counters View

3.4.2.10 View LEC Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.38 illustrates the LEC Counters screen for interfaces supported by an ATM module.

ES-3810 ELAN 3 (Engineering)	LEC Counters	1 18:51:39.15
SVC Failures:	0	
Control Packets Received:	0	
Control Packets Sent:	0	
ARP Replies Received:	0	
ARP Replies Sent:	0	
ARP Requests Received:	0	
ARP Requests Sent:	0	
Join Calls:	0	
Topology Change Indications:	0	

Hit <Enter> to continue.

Figure 3.38 - LEC Counters View

3.4.2.11 View Signaling Counters

This view is reached from the Main Menu through the Interface Selection screen then through the Manage Interface Menu. Figure 3.39 illustrates the Signaling Counters screen for interfaces supported by an ATM module.




Figure 3.39 - Signaling Counters View

VLAN Management

This chapter provides information about managing virtual LANs (VLANs) on the ES-3810. For more information about using VLANs, see Appendix A in the *ForeRunner ES-3810 Installation and Maintenance Manual*.

4.1 Manage VLAN Menu

This menu displays commands that provide access to managed objects that monitor and control the VLANs. This menu is reached from the Main Menu through the Manage VLAN option. Figure 4.1 illustrates the Manage VLAN Menu.




Figure 4.1 - Manage VLAN Menu

The items in the previous menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Select Another VLAN Returns to the VLAN Selection Menu.

View VLAN Displays the VLAN View screen for the selected VLAN.

Create VLAN Queries the user for the name of the new VLAN, the ports that are to belong to that VLAN, whether or not IP multicast filtering is to be enabled, a MAC address to add to the VLAN, whether or not to join the new VLAN, the configuration ("auto" or "manual"), and whether or not to use the default LECS address. **Modify VLAN** Displays the VLAN Selection screen and then queries the user for a new name for the selected VLAN and new ports that are to belong to that VLAN. Displays the Delete VLAN Menu and queries the **Delete VLAN** user for the number of the VLAN to be deleted. Rename VLAN Displays the Rename VLAN Menu and queries the user for the number of the VLAN to be renamed.

Displays the VLAN Inventory View screen.

4.1.1 Modify VLAN Menu

View VLAN Inventory

Selecting Modify VLAN from the Manage VLAN Menu, causes the Modify VLAN menu being displayed (see Figure 4.2).




Figure 4.2 - Modify VLAN Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.

Return to Previous Menu Returns to the Manage VLAN Menu.

Add Port to VLAN Queries the user for the port(s) to add to the selected VLAN and whether or not IP multicast filtering is to

be enabled.

Delete Port from VLAN Queries the user for the port(s) to be deleted from the

selected VLAN.

Add MAC Address to VLAN Queries the user for the MAC address(es) to be

added to the selected VLAN.

Delete MAC Address from VLAN Queries the user for the MAC address(es) to be

deleted from the selected VLAN.

Enable/Disable IP Multicast Asks the user whether to enable or disable IP

Filtering for VLAN multicast filtering.

4.1.2 VLAN Selection Menu

Selecting Select Another VLAN from the Manage VLAN Menu, causes the VLAN Selection menu being displayed (see Figure 4.3). This menu prompts for a VLAN from a list of the VLANs defined in the system. Until VLANs are defined, only the default is available.




Figure 4.3 - VLAN Selection Menu

4.1.2.1 VLAN View

Selecting View VLAN from the Manage VLAN Menu, causes the View VLAN screen being displayed (see Figure 4.4).

```
ES-3810 VLAN View VLAN 2 (pubs)

VLAN Number: 2

VLAN Name: pubs

IP Multicast Filtering: Enabled

Member Forts: C1-C6

Member MAC Addresses: 1. 00:00:00:00:01
```

Figure 4.4 - VLAN View

4.1.3 VLAN Inventory View

Selecting View VLAN Inventory from the Manage VLAN Menu, causes the View VLAN Inventory screen being displayed (see Figure 4.5).

```
ES-3810 View VLAN Inventory
                                                              VLAN 2 (public)
  1. default
  2. public
  3. test1
   4. sales2
  5. marketing
  6. training
  7. <Not Configured>
  8. <Not Configured>
  9. <Not Configured>
 10. <Not Configured>
 11. <Not Configured>
 12. <Not Configured>
 13. <Not Configured>
 14. <Not Configured>
 15. <Not Configured>
 16. <Not Configured>
Hit <Enter> to continue._
```

Figure 4.5 - VLAN Inventory View

CHAPTER 5 UDP/IP Management

This chapter describes the menus used to access and configure managed objects that monitor and control the UDP/IP stack.

5.1 Manage UDP/IP Menu

This menu is reached directly from the Main Menu by selecting the Manage UDP/IP option. Figure 5.1 illustrates the Manage UDP/IP Menu.




Figure 5.1 - Manage UDP/IP Menu

The items in the Manage UDP/IP menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Manage ARP Cache Displays the Manage ARP Cache Menu.

Manage IP Parameters Displays the Manage IP Parameters Menu.

Manage IP Routing Table Displays the Manage IP Routing Table Menu.

View ICMP Counters Displays the ICMP Counters screen.

View IP Counters Displays the IP Counters screen.

View UDP Counters Displays the UDP Counters screen.

5.1.1 Manage ARP Cache Menu

This menu displays commands that provide access to managed objects that monitor and control the ARP cache. This menu is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the Manage ARP Cache option. Figure 5.2 illustrates the Manage ARP Cache Menu.




Figure 5.2 - Manage ARP Cache Menu

The items in the Manage ARP Cache Menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage UDP/IP Menu.

View ARP Cache Displays the ARP Cache View screen.

Displays the First Cache view serecii.

NOTE

Queries the user for an IP address and an associated physical address. If the information provided by the user is valid, an entry does not already exist with the specified IP address, and the ARP cache is not full, then the management console adds an entry to the ARP cache. If the ARP entry could not be added to the ARP cache, then the management console displays an appropriate error message.

Entries added to the ARP cache through the management console always have a fixed state. The management console considers ARP cache entries with the fixed state part of the system's configuration, thereby making them persistent.

Modify ARP Entry

Create ARP Entry

Queries the user for an IP address. If the information provided by the user is valid, and the specified entry exists in the ARP cache, then the management console asks the user for a new physical address. If the specified entry does not exist in the ARP cache, then the management console displays an appropriate error message.

Delete ARP Entry

Queries the user for an IP address. If the information provided by the user is valid, and the specified entry exists in the ARP cache, then the management console deletes the specific entry from the ARP cache. The management console confirms the action. If the specified entry does not exist in the ARP cache, then the management console displays an appropriate error message.

Flush ARP Cache

Deletes all entries that do not have a fixed state from the ARP cache. The management console explains and confirms this action with the user.

5.1.1.1 ARP Cache View

This view is reached through the Manage UDP/IP Menu (see Figure 5.1), then through the Manage ARP Cache Menu (see Figure 5.2) by selecting the View ARP Cache option. Figure 5.3 illustrates the ARP Cache View screen.




Figure 5.3 - ARP Cache View

5.1.2 Manage IP Parameters Menu

This menu displays commands that provide access to managed objects that monitor and control the IP parameters. This menu is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the Manage IP Parameters option. Figure 5.4 illustrates the Manage IP Parameters Menu.

```
ES-3810 Manage IP Parameters Menu

1) Return to Main Menu
2) Return to Previous Menu
3) View IP Parameters

4) Modify IP Address
5) Modify Subnet Mask
6) Modify Primary Gateway
```

Figure 5.4 - Manage IP Parameters Menu

The items in the Manage IP Parameters Menu have the following meanings:

Returns to the Main Menu. Return to Main Menu Returns to the Manage UDP/IP Menu. Return to Previous Menu **View IP Parameters** Displays the IP Parameters View screen. Queries the user for a new IP address. The new IP **Modify IP Address** address defaults to the current IP address if the user provides no input. Queries the user for a new subnet mask. The new **Modify Subnet Mask** subnet mask defaults to the class of the current IP address if the user provides no input. **Modify Primary Gateway** Queries the user for a new primary gateway. The new primary gateway defaults to 0.0.0.0 if the user provides no input.

5.1.3 Manage IP Routing Table Menu

This menu displays commands that provide access to managed objects that monitor and control the IP routing table. This menu is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the Manage IP Route Table option. Figure 5.5 illustrates the Manage IP Routing Table Menu.

ES-3810 Manage IP Routing Table Menu

1) Return to Main Menu
2) Return to Previous Menu
3) View IP Routing Table

4) Create IP Routing Entry
5) Modify IP Routing Entry
6) Delete IP Routing Entry

Figure 5.5 - Manage IP Routing Table Menu

The items in the Manage IP Routing Table Menu have the following meanings:

table.

Return to Main Menu

Return to Previous Menu	Returns to the Manage UDP/IP Menu.
View IP Routing Table	Displays the IP Routing View screen.
Create IP Routing Entry	Queries the user for an IP address, a subnet mask, the next-hop address, and a simple routing metric. If the information provided by the user is valid, an entry does not already exist with the specified IP address, and the IP routing table is not full, then the management console adds an entry to the IP routing

Returns to the Main Menu.

Modify IP Routing Entry

Displays the IP routing entries and asks the user to select one. Next, the management console presents the user with the Modify IP Routing Entry Menu. If the specified entry does not exist in the IP routing table, then the management console displays an

appropriate error message.

Delete IP Routing Entry

Queries the user for an IP address. If the information provided by the user is valid, and the specified entry exists in the IP routing table, then the management console deletes the specific entry from the IP routing table. The management console confirms the action. If the specified entry does not exist in the IP routing table, then the management console displays an appropriate error message.

5.1.3.1 IP Routing Table View

This menu is reached from the Manage UDP/IP Menu (see Figure 5.1), then through the Manage IP Routing Table Menu (see Figure 5.5) by selecting the View IP Routing Table option. Figure 5.6 illustrates the IP Routing Table View screen.

IP Routing Tab.	le View				0 00:14:58.99
IP Address	Network Mask	Gateway	Metric	Fixed	Creator
123.234.12.34 123.234.12.0 Default	255.255.255.255 255.255.255.0 255.0.0.0	Direct Direct 100.200.210.220	o		Operational SW Operational SW Operational SW

Figure 5.6 - IP Routing Table View

5.1.3.2 Modify IP Routing Entry Menu

This menu displays commands that provide write access to managed objects that define the specified IP routing entry. This menu is reached from the Manage UDP/IP Menu (see Figure 5.1) through the Manage IP Routing Table Menu (see Figure 5.5) by selecting the Modify IP Routing Entry option. Figure 5.7 illustrates the Modify IP Routing Entry Menu.



An IP route entry must be selected in the IP Route Entry Selection screen before this menu can be reached.

ES-3810 Modify IP Routing Entry Menu	123.234.12.0
1) Return to Main Menu	
2) Return to Previous Menu	
3) Modify Subnet Mask	
4) Modify Next Hop	
5) Modify Metric	
Please enter selection: _	

Figure 5.7 - Modify IP Routing Entry Menu

The items in the Modify IP Routing Entry Menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage IP Routing Table Menu.

Modify Subnet Mask Queries the user for a new subnet mask for the

specified IP routing entry. The new subnet mask defaults to the current subnet mask if the user

provides no input.

Modify Next Hop Queries the user for a new next-hop address for the

specified IP routing entry. The new next-hop address defaults to the current next-hop address if the user

provides no input.

Modify Metric Queries the user for a new metric for the specified IP

routing entry. The new metric defaults to the current

metric if the user provides no input.

5.1.4 ICMP Counters

This view is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the View ICMP Counters option. Figure 5.8 illustrates the ICMP Counters screen where Inbound and Outbound ICMP counters can be viewed.

Inbound		Outbound	
otal Messages	0	Total Messages	0
otal Errors	0	Total Errors	0
estination Unreachable Msgs	0	Destination Unreachable Msgs	0
ime Exceeded Messages	0	Time Exceeded Messages	0
Parameter Problem Msgs	0	Parameter Problem Msgs	0
Source Quench Messages	0	Source Quench Messages	0
Redirect Messages	0	Redirect Messages	0
Icho Requests	0	Echo Requests	0
Echo Replies	0	Echo Replies	0
imestamp Requests!	0	Timestamp Requests	0
imestamp Replies	0	Timestamp Replies	0
Address Mask Requests	0	Address Mask Requests	0
Address Mask Replies	0	Address Mask Replies	0

Figure 5.8 - View ICMP Counters

5.1.5 IP Counters

This view is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the View IP Counters option. Figure 5.9 illustrates the IP Counters screen.




Figure 5.9 - View IP Counters

5.1.6 UDP Counters

This view is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the View UDP Counters option. Figure 5.10 illustrates the UDP Counters screen.




Figure 5.10 - UDP Counters View

5.1.7 **Ping**

This view is reached from the Main Menu through the Manage UDP/IP Menu (see Figure 5.1) by selecting the Ping option. Figure 5.11 illustrates the Ping screen.

```
IP Destination [147.128.20.253]: 147.128.20.253
Data Length [64]: 64

Hit RETURN to stop PING at any time.

Ping Statistics

Requests Sent : 2
Replies Received: 0
Packet Loss : 100%
Minimum RTT : not applicable
Maximum RTT : not applicable
Average RTT : not applicable

Hit RETURN to continue:
```

CHAPTER 6 SNMP Management

This chapter describes the menus used to access and configure managed objects that monitor and control the SNMP-based management agent.

6.1 Manage SNMP Menu

This menu is reached directly from the Main Menu through the Manage SNMP option. Figure 6.1 illustrates the Manage SNMP Menu.




Figure 6.1 - Manage SNMP Menu

The items in the previous menu have the following meanings:

Return to Main Menu Returns to the Main Menu. Displays the Manage Access Control List Menu. **Manage Access Control List** Displays the Manage Trap Destination List Menu. **Manage Trap Destination List**

View SNMP Counters Displays the SNMP Counters screen.

6.1.1 Manage Access Control List Menu

This menu displays commands that provide write access to managed objects that define the specified IP routing entry. These commands provide access to managed objects that monitor and control the access control list used by the SNMP-based agent for the purpose of authentication. The logon process also uses the access control list.

Entries can be added, deleted, and modified from the Access Control List. Communities and clients can be added to this list to give certain privileges to certain users. For example, you can add the community "Marketing," and provide read-only privileges. The username for a community is the community name.

This menu is reached from the Main Menu through the Manage SNMP Menu, then through the Manage Access Control List option. Figure 6.2 illustrates the Manage Access Control List Menu.




Figure 6.2 - Manage Access Control List Menu

The items in the previous menu have the following meanings:

Return to Main Menu	Returns to the Main Menu.
Return to Previous Menu	Returns to the Manage SNMP Menu.
View Access Control List	Displays the Access Control List screen, listing

communities and their IP addresses and clients.

Add Entry Queries the user for a new community name and whether or not that community has write privileges.

Delete Entry Displays a list of existing entries (communities) in the access control list and asks the user to select the

entry to be deleted.

Modify Entry Displays a list of existing entries (communities) in the access control list and asks the user to select the entry to be modified, the new name for the entry, and

the read-write privileges of the entry.

Add Client Displays a list of existing entries (communities) in the access control list and asks the user to select the entry to which a client is to be added. Next, the user is asked for the IP address, IP address mask, whether the client is to have write access (if the community to which it belongs has write access), and whether the

client is to have read access.

NOTE

A client cannot have more privileges than the community to which it belongs (i.e., a client in a "read-only" community cannot have write access).

Delete Client

Displays a list of existing entries (communities) in the access control list and asks the user to select the entry from which a client is to be deleted. Next, a list of clients in the selected community is displayed, and the user is asked which client from the list is to be deleted.

Modify Client

Displays a list of existing entries (communities) in the access control list and asks the user to select the entry containing the client to be modified. Next, a list of clients in the selected community is displayed, and the user is asked which client from the list is to be modified. The user must supply the client's new IP address, IP address mask, whether the client is to have write access (if the community to which it belongs has write access), and whether the client is to have read access.

6.1.1.1 Access Control List View and Community Selection

This view is reached from the Main Menu through the Manage SNMP Menu, then through the Manage Access Control List Menu, and finally through the View Access Control List option. Figure 6.3 illustrates the Access Control List View screen.




Figure 6.3 - Access Control List View

6.1.1.2 Client List View

This view is reached from the Main Menu through the Manage SNMP Menu, then through the Manage Access Control List Menu, and finally through the View Access Control List option by typing in a community ID from the Access Control List (see Figure 6.3). Figure 6.4 illustrates the Access Control List View screen.

Id	Client Address	Client Mask	Rights
1	147.128.20.252	255.255.255.255	RW
2	147.128.20.253	255.255.255.255	R
3	147.128.20.254	255.255.255	R
		-	'

Figure 6.4 - Client List View

6.1.2 Manage Trap Destination List Menu

This menu displays commands that provide access to managed objects that monitor and control the trap destination list used by the SNMP-based agent to determine where to send traps. This menu is reached from the Main Menu through the Manage SNMP Menu. Figure 6.5 illustrates the Manage Trap Destination List Menu.

```
ES-3810 Manage Trap Destination List Menu

1) Return to Main Menu
2) Return to Previous Menu
3) View Trap Destination List
4) Create Trap Destination Entry
5) Modify Trap Destination Entry
6) Delete Trap Destination Entry
```

Figure 6.5 - Manage Trap Destination List Menu

The items in the previous menu have the following meanings:

Return to Main Menu Returns to the Main Menu.

Return to Previous Menu Returns to the Manage SNMP Menu.

View Trap Destination List Displays the Trap Destination List View.

Create	Trap	Destination	Entry
--------	------	-------------	--------------

Queries the user for an IP address and a community name. If the information provided by the user is valid, and an entry matching the specified IP address does not already exist in the trap destination list, and the trap destination list is not full, then the management console adds the entry to the trap destination list. If the management console could not add the entry to the trap destination list, then the management console displays an appropriate error message in the error message component of the Manage Trap Destination List Menu. Note that trap destination entries are persistent.

Modify Trap Destination Entry

Displays the Trap Destination Selection screen and then queries the user for a new community. The new community defaults to the current community if the user provides no input.

Delete Trap Destination Entry

Displays the Trap Destination List View screen and then asks the user to confirm the selection before deleting the entry.

6.1.2.1 View Trap Destination List

This view is reached from the Main Menu through the Manage SNMP Menu, and then through the Manage Trap Destination List Menu by choosing the View Trap Destination List option. Figure 6.6 illustrates the Trap Destination List View screen.

s-38	310 Trap Destinat:	ion List	0 05:27:02.20
Id	Client	Community	
1 2 3 4	12.34.23.45 34.56.123.12 123.234.12.34 255.0.0.0	sales marketing public private	

Figure 6.6 - View Trap Destination List

6.1.3 SNMP Counters

This view is reached from the Main Menu through the Manage SNMP Menu, using the View SNMP Counters option. Figure 6.7 illustrates the View SNMP Counters screen.




Figure 6.7 - View SNMP Counters

SNMP Management



Spanning Tree Management

This section provides an overview of Spanning Tree bridging and details the menus used to manage and configure it on the ES-3810.

7.1 Overview

A bridge accepts packets of data passing through a network and decides whether to forward each packet based on the information it contains. Bridges operate at the physical and data link layers of the Open Systems Interconnection (OSI) model. The physical layer provides the physical connection to the transmission medium, and the data link layer provides reliable transmission. Specifically, the data link layer is made up of two distinct tasks, Logical Link Control (LLC) and Media Access Control (MAC) (see Figure 7.1).




Figure 7.1 - Overview of IEEE Protocols

The LLC controls the logical link (i.e., it serves to open, maintain, and terminate links). The LLC depends upon the physical layers to perform its tasks.

The MAC controls access to the physical media, acting independently of the physical layer and providing an interface to the upper layers of the network model. IEEE 802.3 and Ethernet use the same MAC layer, allowing both types of packets to coexist on the same cable. In this way, the same bridge can forward both Ethernet and IEEE 802.3 packets.

Bridging allows any IEEE 802-compliant station to communicate with remote, bridged stations as if they were local. Although bridged networks remain physically separate, they appear as one network to other devices.

Bridges forward packets between networks and can pass data using any protocol compatible with the media. Bridges receive all packets from a LAN and examine each one to determine its destination. If the packet is destined for a station on the physical cable from which it was received, the bridge does not forward the packet. If the destination is unknown, the packet is forwarded to all ports except the one on which it was received.

Because bridges examine each packet, and because each packet contains a source address, bridges can easily learn the locations of stations on the network. However, if an address is unknown, flooding can result in endless loops on the network, since all bridges that do not know the address will flood the packet looking for the address. To circumvent this, a tree-type algorithm is implemented that prevents loops and forces the packets into logical routes. This algorithm, called the Spanning Tree Algorithm (STA), allows only one route between any two physical cables or networks.

Spanning tree bridges are based upon a root bridge which exchanges topology information with designated bridges to maintain the configuration. The root and designated bridges notify all other bridges in the network when topology changes are required, thereby preventing loops and reducing the risk of link failure.

7.1.1 Spanning Tree on the ES-3810

The ES-3810 supports up to 16 Spanning Tree instances, or bridges. Each bridge must be configured on a per-port, per-VLAN basis. All ports of a VLAN must be associated with the same Spanning Tree, including the ports of the associated ELAN (denoted as L1, L2, etc.).



More than one VLAN can be associated with a bridge.

Each bridge, internally numbered from 0 to 15, can be named to allow easier identification. At startup, a default bridge (STP 0) is configured. This default instance is named <code>DefaultSpanningTree</code>.

All VLANS and all ports belong to STP 0 by default, and all ports will be initialized with Spanning Tree switched-off. Spanning Tree must be manually activated on desired ports (see the remainder of this chapter for more information on configuring Spanning Tree on the ES-3810).

Spanning Iree Management

7.2 Manage Spanning Tree Menu

The Manage Spanning Tree Menu is available from the Main Menu of the ES-3810 console interface by selecting the Manage Spanning Tree option. Figure 7.2 illustrates the Manage Spanning Tree Menu.




Figure 7.2 - Manage Spanning Tree Menu

7.2.1 Selecting a Spanning Tree Instance

From the Manage Spanning Tree Menu (see Figure 7.2) select the Select Spanning Tree Instance option. When the Select Spanning Tree screen appears, type the number corresponding to the desired Spanning Tree instance and press <ENTER> (see Figure 7.3).

ES-3810 Select Spanning Tree DefaultSpanningT		DefaultSpanningTree
Number	Name	
1 2 3 4	DefaultSpanningTree Spanning Tree 1 Spanning Tree 2 Spanning Tree 3	
Please	enter selection (by Number):	

Figure 7.3 - Select Spanning Tree Menu

7.2.2 Displaying Spanning Tree Bridge Information

After selecting a Spanning Tree instance, you will be returned to the Manage Spanning Tree Menu (see Figure 7.2). To display the bridge information of the selected Spanning Tree instance, select the Display Spanning Tree Bridge Information option. The screens shown in Figure 7.4 and Figure 7.5 are displayed.

Spanning Tree Manag	ement	Bridge Information	0 00:09:34.23
STP Name : Spanning	Tree 1	STP Number 1	
Root Port Number	0 ()	Desig Root Pr	32768
Root Cost	0	Desig Root Ad	00-A0-36-00-05-61
Topology Changes O		Bridge Priority	32768
Hold Time	1 secs	Bridge Address	00-A0-36-00-05-61
Max Age	20 secs	Bridge Max Age	20 secs
Hello Time	2 secs	Bridge Hello Time	2 secs
Forward Delay	15 secs	Bridge Forward Delay	, 15 secs
Enter any key to co	ntinue		

Figure 7.4 - Bridge Information Display (Part 1)

```
Spanning Tree Management Bridge Information 0 00:10:10.64

STP Name: Spanning Tree 1 STP Number 1

Ports configured on STP Spanning Tree 1:

None
Number of Ports = 0

Enter any key to continue_
```

Figure 7.5 - Bridge Information Display (Part 2)

The parameters displayed in Figure 7.4 and Figure 7.5 have the following meanings:

	0 0
STP Name	Indicates the name of the selected bridge. A bridge's name can be assigned or changed by the user. The default bridge name is <code>DefaultSpanningTree</code> .
STP Number	Indicates the number, from 0 to 15, of the selected bridge. STP Number is the internal system identifier of each bridge.
Root Port Number	Indicates the port on the selected bridge that is closest to the Root Bridge, determined by path cost.
Desig Root Pr	Indicates the priority of the root bridge, between 0 and $65,535$.
Root Cost	Indicates the sum of the path costs from the selected bridge to the root.
Desig Root Ad	Indicates the MAC address of the root bridge.
Topology Changes	Indicates the number of times the topology of the selected bridge has changed.
Bridge Priority	Indicates the priority of the selected bridge.
Hold Time	Indicates the hold time, which is a constant value of one second.

Bridge Address Indicates the MAC address of the selected bridge.

Max Age Indicates the maximum amount of time that the

selected bridge will wait to hear Hello Bridge Protocol Data Units (BPDUs) from the root bridge. If the selected bridge does not receive BPDUs from the root bridge within this interval, it assumes that the network has changed and recalculates the spanning

tree topology.

Bridge Max Age Indicates the Max Age of the selected bridge.

Hello Time Indicates the interval between BPDUs.

Bridge Hello Time Indicates the Hello Time for the selected bridge.

Forward Delay
Indicates the amount of time that will be spent

listening for topology changes after a bridging interface is configured and before forwarding begins.

Bridge Forward Delay Indicates the Forward Delay for the selected bridge.

7.2.3 Creating a Spanning Tree Instance

To create a new Spanning Tree instance, select the Create Spanning Tree option from the Manage Spanning Tree Menu (see Figure 7.2). The Create Spanning Tree screen is displayed (see Figure 7.6).




Figure 7.6 - Create Spanning Tree Menu (part 1)

Type the name of the new Spanning Tree and press <ENTER>. Next, select a VLAN to include in the new spanning tree (see Figure 7.7). If you wish to include ports from another VLAN, enter y at the Add More Ports from Vlans [No]? prompt (see Figure 7.7).

```
ES-3810 Create Spanning Tree STP 7 (Spanning Tree 4)

Ports configured on STP Spanning Tree 4:
    None
Select Vlan to include in this Spanning Tree:

1. default

Enter Vlan Number:1

Add More Ports from Vlans [No]? n
```

Figure 7.7 - Create Spanning Tree Menu (part 2)

7.2.4 Modifying Spanning Tree Bridge Information

To modify the bridge information of the selected Spanning Tree instance, select the Modify Spanning Tree Bridge Configuration option from the Manage Spanning Tree Menu (see Figure 7.2). The Modify Spanning Tree Bridge Configuration Menu is displayed (see Figure 7.8).




Figure 7.8 - Modify Spanning Tree Bridge Configuration Menu

Spanning Iree Management

7.2.4.1 Associating a VLAN to a Spanning Tree Instance

To associate a VLAN to the selected Spanning Tree instance, select the Associate VLAN to STP Instance option from the Modify Spanning Tree Bridge Configuration Menu. The Associate VLANs to Spanning Tree screen is displayed (see Figure 7.9). Type the number corresponding to the desired VLAN and press <ENTER>.

```
Associate Vlans to Spanning Tree Spanning Tree 1 0 00:12:19.52

Ports configured on STP Spanning Tree 1:
   None
Select Vlan to include in this Spanning Tree :

1. default

Enter Vlan Number :
```

Figure 7.9 - Associate VLANS to Spanning Tree Menu

7.2.4.2 Modifying Spanning Tree Bridge Priority

To modify the Spanning Tree bridge priority of the selected Spanning Tree instance, select the Modify STP Bridge Priority option from the Modify Spanning Tree Bridge Configuration Menu. The Modify STP Bridge Priority screen is displayed (see Figure 7.10). Type the value of the new bridge priority and press <ENTER>.




Figure 7.10 - Modify STP Bridge Priority Menu

Spanning Iree Management

7.2.4.3 Modifying Spanning Tree Bridge Maximum Age

To modify the Spanning Tree bridge maximum age of the selected Spanning Tree instance, select the Modify STP Bridge MaxAge option from the Modify Spanning Tree Bridge Configuration Menu. The Modify STP Bridge MaxAge screen is displayed (see Figure 7.11). Type the value of the new maximum age and press <ENTER>.

```
Modify STP Bridge MaxAge

Enter STP Bridge Max Age

Allowed Range is [6 - 40] as per relation:

{ 2 * [Forward Delay -1] >= Max Age }

Enter STP Bridge MaxAge [Current 20]:
```

Figure 7.11 - Modify STP Bridge MaxAge Menu

7.2.4.4 Modifying Spanning Tree Bridge Hello Time

To modify the Spanning Tree bridge hello time of the selected Spanning Tree instance, select the Modify STP Bridge Hello Time option from the Modify Spanning Tree Bridge Configuration Menu. The Modify STP Bridge Hello Time screen is displayed (see Figure 7.12). Type the value of the new hello time and press <ENTER>.




Figure 7.12 - Modify STP Bridge Hello Time Menu

panning Iree //anaαement

7.2.4.5 Modifying Spanning Tree Bridge Forward Delay

To modify the Spanning Tree bridge forward delay of the selected Spanning Tree instance, select the Modify STP Bridge Forward Delay option from the Modify Spanning Tree Bridge Configuration menu. The Modify STP Bridge Forward Delay screen is displayed (see Figure 7.13). Type the value of the new forward delay and press <ENTER>.

```
Modify STP Bridge Forward Delay

Enter STP Bridge Forward Delay

Allowed Range is [4 - 30] as per relation :

[2 * [Forward Delay -1] >= Max Age }

Enter STP Bridge Forward Delay [Current 15]:
```

Figure 7.13 - Modify STP Bridge Forward Delay Menu

7.2.5 Deleting a Spanning Tree Instance

To delete a Spanning Tree instance, select the Delete Spanning Tree Instance from the Manage Spanning Tree Menu (see Figure 7.2). When the Delete Spanning Tree screen appears, type the number corresponding to the Spanning Tree instance to be deleted and press <ENTER> (see Figure 7.14).

Number Name 1 DefaultSpanningTree 2 Spanning Tree 1 3 Spanning Tree 2 4 Spanning Tree 3 5 Spanning Tree 4 Please enter selection (by Number):	ES-3810 Delete Spanning Tree Spanning Tree			Tree 1
2 Spanning Tree 1 3 Spanning Tree 2 4 Spanning Tree 3 5 Spanning Tree 4	Number	Name		
	2 3 4 5	Spanning Tree 1 Spanning Tree 2 Spanning Tree 3 Spanning Tree 4		

Figure 7.14 - Delete Spanning Tree Menu

Spanning Iree Management

7.2.6 Displaying Spanning Tree Port Status

To display all the ports of the ES-3810, the Spanning Tree instance to which they belong, and the status of each port, select the Display Spanning Tree Port Status option from the Manage Spanning Tree Menu (see Figure 7.2). When the View STP Port Status Display is shown, press <ENTER> to scroll through the listed ports (see Figure 7.15).

1. DefaultSpanningTree	B1	STP Off
 DefaultSpanningTree 	B2	STP Off
 DefaultSpanningTree 	в3	STP Off
4. DefaultSpanningTree	в4	STP Off
DefaultSpanningTree	в5	STP Off
6. DefaultSpanningTree	В6	STP Off
7. DefaultSpanningTree	в7	STP Off
8. DefaultSpanningTree	в8	STP Off
9. DefaultSpanningTree	C1	STP Off
10. DefaultSpanningTree	C2	STP Off
11. DefaultSpanningTree	c3	STP Off
12. DefaultSpanningTree	C4	STP Off
13. DefaultSpanningTree	C5	STP Off
14. DefaultSpanningTree	C6	STP Off
15. DefaultSpanningTree	c7	STP Off
16. DefaultSpanningTree	C8	STP Off
17. DefaultSpanningTree	C9	STP Off

Figure 7.15 - View STP Port Status Display

7.2.7 Switching-on STP on Ports

To switch-on Spanning Tree on an individual port or groups of ports, select the Switch STP ON on Ports option from the Manage Spanning Tree Menu (see Figure 7.2). When the Switch STP ON screen appears, type the port(s) on which you wish to switch-on Spanning Tree and press <ENTER> (see Figure 7.16).




Figure 7.16 - Switch STP ON Menu

Management

7.2.8 Switching-off STP on Ports

To switch-off Spanning Tree on a port or groups of ports, select the Switch STP OFF on Ports option from the Manage Spanning Tree Menu (see Figure 7.2). When the Switch STP OFF screen appears, type the port(s) on which you wish to switch-off Spanning Tree and press <ENTER> (see Figure 7.17).




Figure 7.17 - Switch STP OFF Menu

7.2.9 Managing Spanning Tree Port Configuration

To manage Spanning Tree on a port, select the Manage Spanning Tree Port Configuration option from the Manage Spanning Tree Menu (see Figure 7.2). The Modify Spanning Tree Port Configuration Menu appears (see Figure 7.18).




Figure 7.18 - Modify Spanning Tree Port Configuration Menu

panning Iree Management

7.2.9.1 Selecting a Spanning Tree Port

To manage Spanning Tree on an individual port, select the Select Spanning Tree Port option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). When the Select Spanning Tree Port screen appears, enter the desired port number and press <ENTER> (see Figure 7.19).

```
Select Spanning Tree Port Port . B1 0 00:04:11.58

Spanning Tree Ports:

B1 - B8
C1 - C16
D1 - D24

Enter Port Identifier (B1-D24): b1
```

Figure 7.19 - Select Spanning Tree Port Menu

7.2.9.2 Displaying Spanning Tree Port Information

To display information for the selected port, select the Display Spanning Tree Port Information option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). The Spanning Tree Management Display is shown (see Figure 7.20).

Spanning Tree Management		Port Information	0 00:04:43.10	
 STP Information for Port	. B1	Desig Root Pr	0	
 Port Priority	128	Desig Root Ad	00-00-00-00-00	
 Port Id	1	Desig Cost	0	
 Port State	STP Off	Desig Bridge Pr)	
 Port Path Cost 	10	Desig Bridge Ad (00-00-00-00-00	
 Designated Port Priority 	. 0	Designated Port Id	0	
 Spanning Tree Instance =	0	STP Name : DefaultS	panningTree	
Enter any key to continue				

Figure 7.20 - Spanning Tree Port Information Menu

panning Iree //anaαement

7.2.9.3 Toggling STP on a Port

To switch STP on or off on the selected port, select the Switch STP ON/OFF on a Port option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). If Spanning Tree is currently set to ON on the port, you will be prompted to turn it OFF. If Spanning Tree is currently set to OFF, you will be prompted to turn it ON. Type \mathbf{y} and press <ENTER> at the prompt to accept, or type \mathbf{n} and press <ENTER> to leave the port unchanged (see Figure 7.21).




Figure 7.21 - Toggle STP on a Port Menu

7.2.9.4 Enabling/Disabling Traffic Forwarding on a Port

To enable or disable traffic forwarding on the selected port, select the Enable/Disable STP on a Port option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). If traffic forwarding is currently enabled on the port, you will be prompted to disable it. If traffic forwarding is currently disabled on the port, you will be prompted to enable it. Type \mathbf{y} and press <ENTER> at the prompt to accept, or type \mathbf{n} and press <ENTER> to leave the port unchanged (see Figure 7.22).




Figure 7.22 - Enable/Disable STP Menu

Spanning Iree Management

7.2.9.5 Modifying STP Port Priority

To modify a port's priority, select the Modify STP Port Priority option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). When the Modify STP Port Priority screen appears, type a new port priority and press <ENTER> (see Figure 7.23).




Figure 7.23 - Modify STP Port Priority Menu

7.2.9.6 Modifying STP Port Path Cost

To modify the path cost on a selected port, select the Modify STP Port Path Cost option from the Modify Spanning Tree Port Configuration Menu (see Figure 7.18). When the Modify STP Port Path Cost screen appears, type a new path cost and press <ENTER> (see Figure 7.24).




Figure 7.24 - Modify STP Port Path Cost Menu

Telnet Management

8.1 Overview

The ES-3810 includes single-session Telnet support for providing remote access to the switch.



Telnet is single session **only** and causes the console to be redirected (i.e., only a telnet session or a local console session can be active at any one time, not both).

To configure Telnet on the ES-3810, log on via the management console and select the Manage Telnet option from the Main Menu. The Manage Telnet Menu is displayed, as shown in Figure 8.1.




Figure 8.1 - The Manage Telnet Menu

8.1.1 Viewing Telnet Parameters

To view the ES-3810's current Telnet configuration, select the View Telnet Parameters option from the Manage Telnet Menu (see Figure 8.1). The Telnet parameters are displayed as shown in Figure 8.2.

ES-3810 View Telnet Parameters

Telnet Logon: Enabled
Telnet Timeout: 000 00:05:00

Hit <Enter> to continue.

Figure 8.2 - View Telnet Parameters Display

The parameters displayed in this screen have the following meanings:

Telnet Logon

Indicates whether or not Telnet access to the ES-3810 is enabled. Enabled indicates that the ES-3810 can be reached via telnet (using the correct IP address). Disabled indicates that the ES-3810 can not be reached via Telnet.

Telnet Timeout

Indicates the current timeout setting for the ES-3810. The timeout parameter (entered in days hours:minutes:seconds) indicates the amount of "idle" time allowed before which the ES-3810 will terminate a Telnet session.

For example, if the timeout value is set to 000 00:05:00 (five minutes), a Telnet session to the ES-3810 will be terminated after five minutes of inactivity.

8.1.2 Enabling/Disabling Telnet

To enable or disable Telnet on the ES-3810, select the Enable/Disable Telnet option from the Manage Telnet Menu (see Figure 8.1). The selection must be confirmed (whether enabling or disabling Telnet), as shown in Figure 8.3.




Figure 8.3 - Enable/Disable Telnet Confirmation Screen

If Telnet is disabled, the following message is displayed: Enable Telnet [Yes]?

- 1. To enable Telnet:
 - Type **y** and press <ENTER>, or simply press <ENTER>.
- 2. To leave Telnet disabled:
 - Type n and press <ENTER>.
 - Next, press <ENTER> again to return to the Manage Telnet Menu.

If Telnet is enabled, the following message is displayed: Disable Telnet [Yes]?

- 1. To disable Telnet:
 - Type **y** and press <enter>, or simply press <enter>.
- 2. To leave Telnet enabled:
 - Type n and press <ENTER>.
 - Next, press <ENTER> again to return to the Manage Telnet Menu.

8.1.3 Modifying the Timeout Value

To change or disable the Telnet timeout value on the ES-3810, select the Modify Telnet Timeout option from the Manage Telnet Menu (see Figure 8.1). The screen shown in Figure 8.4 is displayed.

```
ES-3810 Modify Telnet Timeout

Telnet Timeout [5:00]: 000 00:10:00_

Please enter a delta time value using the following format:

[ddd hh:mm:]ss

where ddd = days (<12)
hh = hours (<24)
mm = minutes (<60)
ss = seconds (<60)

Delta time should be >= 10secs AND <= 1000000secs

Enter a zero (0) value to disable the function.
```

Figure 8.4 - Timeout Modification Screen

To change the Telnet timeout value, enter the new value according to the key in the lower portion of the screen. For example, to change the value to 10 minutes, enter $000 \ 00:10:00$. Ten minutes can also be entered as 10:00, or as 600 (seconds).



To return to the Manage Telnet Menu without modifying the timeout value, press <ENTER> before entering anything else.



To disable the timeout feature altogether, enter 0 as the timeout value.

8.1.4 Viewing TCP Connections

To view the TCP connections on the ES-3810, select the View TCP Connections option from the Manage Telnet Menu (see Figure 8.1). The screen shown in Figure 8.5 is displayed.

```
Local Address Foreign Address (state)
.V.VHit Enter To Continue_
```

Figure 8.5 - TCP View Display

Telnet Management

CHAPTER 9

MPOA Management

This chapter provides an overview of Multiple Protocol over ATM (MPOA) and details the menus used to manage MPOA on the ES-3810. These menus are available by selecting the Manage MPOA option from the ES-3810 Main Menu.

9.1 MPOA Overview

MPOA integrates LAN Emulation (LANE) and Next Hop Resolution Protocol (NHRP) to preserve the benefits of LANE, while allowing inter-subnet, internetwork layer protocol communication over ATM VCCs without requiring routers in the data path. MPOA provides a framework for effectively synthesizing bridging and routing with ATM in a diverse environment, providing a unified paradigm for overlaying internetwork layer protocols on ATM. Using both routing and bridging information, MPOA is capable of locating the optimal exit from the ATM cloud.

By employing virtual routing—the physical separation of internetwork layer route calculation and forwarding—MPOA provides a number of key benefits:

- Efficient inter-subnet communication;
- Increased manageability through the reduction of the number of devices that must be configured to perform internetwork layer route calculation;
- Increased scalability through the reduction of the number of devices participating in internetwork layer route calculations.

Through the use of virtual routing, MPOA reduces the complexity of edge devices, such as the ES-3810, by eliminating the need for these devices to perform internetwork layer route calculations.

The primary goal of MPOA is the efficient transfer of unicast data. To accomplish speed and efficiency of data transfer, MPOA utilizes the strengths of ATM network topology and configuration to effectively link up shortcuts between a source and destination. MPOA components establish shortcut VCCs between each other as necessary to transfer data and control messages over an ATM network.

9.1.1 MPOA Shortcuts

A shortcut is a direct one-hop path to a destination or to the nearest transit point to a destination. For a shortcut to be established: an ingress (destined toward the ATM cloud) MPC must first have been configured on the originating device; all routers connecting the originating device to the terminating device must have been configured with MPSes; and the terminating device must a have an MPC or MPS configured.

Default forwarding for the MPOA System occurs via routers. When an MPC becomes aware of a particular traffic flow that could benefit from a shortcut, the ingress MPC needs to determine the ATM address associated with the egress device (outside of the ATM cloud). To obtain the ATM address for a shortcut, the ingress MPC sends an MPOA Resolution Request to the appropriate ingress MPS. When this MPS is able to resolve the resolution request, a reply is returned to the ingress MPC that contains an ATM address of the egress device.

If a shortcut is established, the ingress MPC strips the DLL encapsulation from the packet and sends it via the shortcut. When the packet arrives via shortcut at the egress MPC, it is examined and either a matching egress cache entry is found or the packet is dropped. All encapsulated information is stored at the egress MPC/MPS and is inserted at the egress point before being passed on to legacy ports.

9.1.2 MPOA Components

MPOA is designed with a client/server architecture. There are two types of MPOA logical components: MPOA Clients (MPC) and MPOA Server(s) (MPS). An MPC can service one or more LECs and communicates with one or more MPSes. An MPS converts between MPOA requests and replies and NHRP requests and replies on behalf of the MPCs.

In its ingress role, an MPC detects flows of packets that are being forwarded over an ELAN to a router that contains an MPS. When it recognizes a flow that could benefit from a shortcut that bypasses the routed path, it uses an NHRP-based query-response protocol to request the information required to establish a shortcut to the destination. If a shortcut is available, the MPC caches the information in its egress cache, sets up a shortcut VCC, and forwards frames for the destination over the shortcut.

In its egress role the MPC receives internetwork data frames from other MPCs to be forwarded to its local interfaces/users. For frames received over a shortcut, the MPC adds the appropriate DLL encapsulation and forwards them to the higher layers (e.g., a bridge port or an internal host stack). The DLL encapsulation information is provided to the MPC by an egress MPS and stored in the MPC's egress cache.

An MPS is the logical component of a router that provides internetwork layer forwarding information to MPCs. A full NHS, as defined in NHRP, is included in the MPS. The MPS interacts with the local NHS to answer MPOA queries from ingress MPCs and provide encapsulation information to egress MPCs.

9.1.3 MPOA Information Flows

The MPOA solution involves a number of information flows that can be categorized as MPOA control flows and MPOA data flows. By default, all control and data flows are carried over ATM VCCs using LLC/SNAP (RFC 1483) encapsulation. Configuration flows use the formats described in LANE; MPSs and MPCs communicate with the LAN Emulation Configuration Server (LECS) to retrieve configuration information.

MPC-MPS control flows are used for MPC cache management. The MPOA Resolution Request/Reply allows the ingress MPC to obtain shortcut information. The ingress MPS may trigger the ingress MPC to make a request by sending the MPOA Trigger Message. The MPOA Cache Imposition Request/Reply allows the egress MPS to give the egress MPC egress cache information. Finally, either the egress MPC or an MPS may send a Purge message if it discovers that cached information has become invalid.

MPS-MPS control flows are handled by standard internetwork layer routing protocols and NHRP. MPOA does not define any new MPS-MPS protocols. MPOA requires no new replication techniques and relies upon the standard techniques provided by LANE and internetwork layer routing protocols.

MPC-MPC control flows are used to invalidate erroneous cache information. An egress MPC may send a data plane purge to an ingress MPC if it receives misdirected packets from that MPC. This causes the MPC to invalidate its erroneous cache information.

MPC-MPC data flows are used primarily for the transfer of data between MPCs over MPOA shortcut VCCs.

MPC-NHC data flows are used to allow an MPC to send unicast data to an NHC and to allow an NHC to send unicast data to an MPC.

9.1.4 MPOA Operations

MPOA performs the following operations: configuration, discovery, target resolution, connection management, and data transfer. These operations are described in the following subsections.

9.1.4.1 Configuration

MPCs and MPSes require configuration. By default, MPOA components retrieve their configuration parameters from the LECs.



MPOA components must be able to configure via the LECs.

9.1.4.2 Discovery

To reduce operational complexity, MPOA components automatically discover each other (i.e., the MPC's and MPSs "learn" of each other's existence) using extensions to the LANE LE_ARP protocol that carry the MPOA device type (MPC or MPS) and ATM address. This information is discovered dynamically and used as needed.



MPCs are not NHCs and do not register host internetwork layer addresses with NHSes using NHRP Registration.

9.1.4.3 Target Resolution

MPOA target resolution uses an extended NHRP Resolution Request protocol to allow MPCs to determine the ATM address for the end points of a shortcut. The protocol is interpreted from different perspectives by the ingress MPC, the ingress MPS, the egress MPS and the egress MPC.

An ingress MPC learns the MAC addresses of MPSes attached to its ELAN from the device type TLVs in LE_ARP responses. The MPC is required to perform flow detection, based on internetwork layer destination addresses, on packets destined for these learned MAC addresses. Additionally, an MPC is permitted to perform other types of flow detection.

The ingress MPS processes MPOA Resolution Requests sent by local MPCs. The ingress MPS can answer the request if the destination is local; otherwise, it re-originates the request along the routed path through its local NHS. To insure that the reply is returned to the originating MPS, the ingress MPS uses its internetwork layer address as the source protocol address in the re-originated request. All other fields from the MPOA resolution request are copied, in particular the MPC's data ATM address, which is used as the NBMA address, and all TLVs.



A new Request ID is set by the ingress MPS for the re-originated request so that downstream NHSes do not cache the association of the resulting internetwork layer and ATM addresses. On receiving a reply, the ingress MPS restores the Request ID field and source protocol address and returns an MPOA Resolution Reply to the ingress MPC.

The egress MPS sources an MPOA Cache Imposition Request when an NHRP Resolution Request targeted for a local MPC arrives at the egress MPS serving that MPC. After receiving the MPOA Cache Imposition Reply from the egress MPC, the egress MPS sends an NHRP Resolution Reply toward the request originator. Additional information requested by the ingress MPC (and included in the MPOA Cache Imposition Request and the MPOA Cache Imposition Reply messages) must be included in the NHRP resolution as well.

The egress MPC must send an MPOA cache Imposition Reply for every MPOA Cache Imposition Request. To formulate its reply, the MPC must determine if it has the resources to maintain the cache entry and potentially receive a new VCC. If the MPC cannot accept either the cache entry or the VCC that might result from a positive reply, it sets the appropriate error status and returns the MPOA Cache Imposition Reply to the MPS. If the MPC can accept this cache entry, it inserts an ATM address and may modify the MPOA Egress Cache Tag Extension (if present) to be used by the ingress MPC in connection with this shortcut, sets a success status, and sends the MPOA Cache Imposition Reply to the egress MPS.



In some configurations, it is possible for an egress MPC to receive conflicting next-hop forwarding instructions for the same source ATM address and internetwork layer address pair. If this conflict occurs, the egress MPC will take one of the following actions to ensure that packets are forwarded properly: an appropriate tag in the MPOA cache Imposition Reply may be included; a distinct destination ATM address may be included in the MPOA Cache Imposition Reply; or, the imposition request may be refused.

9.1.4.4 Connection Management

MPOA components establish VCCs between each other as necessary to transfer data and control messages over an ATM network. For the purpose of establishing control VCCs, MPOA components learn of each other's existence through the discovery process described above. For the purpose of establishing data VCCs, MPOA components learn of each other's existence through the resolution process described above.

9.1.4.5 Data Transfer

The primary goal of MPOA is the efficient transfer of unicast data. Unicast data flow through the MPOA system has two primary modes of operation: the default flow and the shortcut flow. The default flow follows the routed path over the ATM network. In the default case, the ES-3810 acts as a Layer 2 bridge. Shortcuts are established by using the MPOA target resolution and cache management mechanism.



When an MPC has an internetwork protocol packet to send for which it has a shortcut, the ES-3810 acts as an internetwork level forwarder and sends the packet over the shortcut.

9.2 Manage MPOA Menu

The Manage MPOA Menu (see Figure 9.1) is reached from the Main Menu of the ES-3810 console interface by selecting the Manage MPOA option.




Figure 9.1 - Manage MPOA Menu

Return to Main Menu	Returns to the Main Menu.
Select Another ELAN	Returns to the ELAN Selection Menu.
Manage MPC Configuration	Displays the Manage MPC Menu.
View MPC Status	Displays the MPC Status view.
View MPC Ingress Cache	Displays the MPC Ingress Cache view.
View MPC Egress Cache	Displays the MPC Egress Cache view.
View MPC MPS Table	Displays the MPC MPS Table view.
View MPOA Shortcut Routes	Displays the MPOA Shortcut Routes view.
View MPC counters	Displays the MPC Counters view.

9.2.1 Manage MPC Configuration Menu

To view the Manage MPC Configuration Menu (see Figure 9.2), select the Manage MPC Configuration option from the Manage MPOA Menu (see Figure 9.1).

ES-3810 Manage MPC Configuration Menu

1) Return to Main Menu
2) Return to Previous Menu

3) Enable/Disable MPC
4) Config Mode
5) Configuration Mask
6) Control/Data ATM Address
7) Shortcut Setup Frame Count
8) Shortcut Setup Frame Time
9) Initial Retry Time
10) Retry Maximum
11) Hold Down Time

Please enter selection:

Figure 9.2 - Manage MPC Configuration Menu

Return to Main Menu Returns you to the Main Menu. **Return to Previous Menu** Returns you to the Manage MPOA. **Enable/ Disable MPC** In this menu you can change the state of the MPC. When an MPC changes states it rejoins the ELAN. In this menu you can change the state of the MPC **Config Mode** from manual to automatic. This menu is for debugging purposes. **Configuration Mask** Control/ Data ATM address This menu allows you to change the control ATM address (used for MPOA control information) and the data ATM address (used to set up shortcut VCs). **Shortcut Setup Frame Count** This menu allows you to modify shortcuts and frame counts. **Shortcut Setup Frame Time** This menu allows you to modify shortcuts and frame time.



The MPC will initiate a shortcut when it sees the numbers specified in the shortcut frame time and count. For instance, if the frame count is set at 10 and the time is set at 1-second, the MPC will initiate a shortcut when it sees 10 frames in 1-second.

Initial Retry Time When the MPC does not receive a shortcut resolution

response, then it will wait for this initial retry time

before trying the resolution again.

Retry Maximum Each time the MPC fails to get a response, it will wait

for a longer time. This the limit on that amount of

time.

Hold Down Time The minimum amount of time to wait before re-

initiating a failed resolution attempt.

9.2.1.1 Enabling and Disabling MPC

This screen is reached from the Manage MPC Menu (see Figure 9.2); in it you will be prompted to switch states of the MPC, so that it is either enabled or disabled.



When an MPC changes states it rejoins the ELAN.

9.2.1.2 Configuration Mode

This screen is reached from the Manage MPC Menu (see Figure 9.2); in it you will be prompted to switch states of the MPC from manual to automatic.



When an MPC changes states it rejoins the ELAN.



If the configuration mode is automatic, all of the MPOA parameters are taken from LECs. In manual mode, parameters are locally assigned defaults. You can change these in the MPC Configuration Menu.

9.2.1.3 Enabling/Disabling MPCs on an ELAN

To reach the Enable/Disable view (see Figure 9.3) select the Enable/Disable MPC option from the Manage MPC Configuration Menu (see Figure 9.2). In this screen you are allowed to enable or disable MPC on an ELAN.

```
The current ELAN's mpc is Disabled.

Do you want to change it to Enabled? [No]? y
Enter MPC Configuration Mode: 1=Auto; 2=Manual [1]?1
Enabling MPOA Client 0
Enabling MPOA Client 16

Hit <Enter> to continue.
```

Figure 9.3 - MPC Enable/Disable View

9.2.1.4 Shortcut Setup Frame Count

To reach the Shortcut Setup Frame Count view (see Figure 9.4) select the Shortcut Setup Frame Count option from the Manage MPC Menu (see Figure 9.2). This menu allows you to modify shortcut frame time.



The MPC will initiate a shortcut based on the numbers specified in the shortcut frame time and count. For instance, if the frame count is set at 10 and the time is set at 1-second, the MPC will initiate a shortcut when 10 frames in 1-second are specified.

```
The current shortcut setup Frame Count is 10.

Enter the new Frame Count[1 - 65535]: _
```

Figure 9.4 - Shortcut Frame Count

9.2.1.5 Shortcut Setup Frame Time

To reach the Shortcut Setup Frame Time view (see Figure 9.5) select the Shortcut Setup Frame Time option from the Manage MPC Menu (see Figure 9.2). This screen allows you to modify shortcuts and frame count.



The MPC will initiate a shortcut when it sees the numbers specified in the shortcut frame time and count. For instance, if the frame count is set at 10 and the time is set at 1-second, the MPC will initiate a shortcut when it sees 10 frames in 1-second.

```
The current shortcut setup Frame Time is 1.

Enter the new Frame Time[1 - 60]: _
```

Figure 9.5 - Shortcut Frame Time

9.2.1.6 Initial Retry Time

To reach the Initial Retry Time view (see Figure 9.6) select the Initial Retry option from the Manage MPC Configuration menu (see Figure 9.2). In this screen you are allowed to change the initial retry time.

```
The current Initial Retry Time is 1431655765.

Enter the new Retry Time[1 - 300]:
No change is made.

Hit <Enter> to continue.
```

Figure 9.6 - Initial Retry Time

Initial Retry Time

When the MPC does not receive a shortcut resolution response, then it will wait for this initial retry time before trying the resolution again.

9.2.1.7 Retry Maximum

To reach the Retry Maximum view (see Figure 9.7) select Retry Maximum from the Manage MPC Configuration menu (see Figure 9.2). This screen allows you to change the maximum amount of time that the MPC will wait before trying to get a response after the initial attempt has failed.

```
The current Retry Maximum is -1431655766.

Enter the new Retry Maximum[10 - 300]:

No change is made.

Hit <Enter> to continue._
```

Figure 9.7 - Retry Maximum

Retry Maximum

The limit on the amount of time that the MPC will wait to get a shortcut resolution response.



Each time the MPC fails to get a response, it will wait for a longer time, unless Retry Maximum is set to limit that amount of time.

9.2.1.8 Hold Down Time

To reach the Hold Down Time view (see Figure 9.8) select the Hold Down Time option from the Manage MPC Configuration menu (see Figure 9.2). This screen allows you to change the preset hold down time.

```
The current Hold Down Time is 1431655765.

Enter the new Hold Down Time[30 - 1200]: 40

Hit <Enter> to continue.
```

Figure 9.8 - Hold Down Time

Hold Down Time

The minimum amount of time the MPC will wait before re-initiating a failed shortcut resolution attempt.

9.2.2 MPC Status

To reach the MPC Status View (see Figure 9.9) select View MPC Status from the Manage MPOA menu (see Figure 9.1). This screen allows you to switch the state of the MPC status from Disabled to In Service.

```
ES-3810 View MPC Status

MPC state

Config Mode

MPC actual ctrl Atm Addr

MPC actual data Atm Addr

MPC Actual Auth Type

MPC shortcut setup frame count

MPC shortcut setup frame time

MPC initial retry time

MPC retry maximum

MPC hold down time

Quit Switch =>

Enabled/Waiting for Configuration

Automatic

Putomatic

Automatic

Automatic
```

Figure 9.9 - MPC Status View

MPC State Displays the operational status of the MPC, which is

either in service, waiting for configuration

information, or disabled.

Config Mode This mode is either manual or automatic.

MPC Actual Control ATM Address Displays the address of the control ATM (used for

MPOA control information) and the data ATM

address (used to set up shortcut VCs)

to set up shortcut VCs).

MPC Actual Auth Type Displays the authentication type.

MPC Shortcut Setup Frame Count Displays shortcut setup frame count.

MPC Shortcut Setup Frame Time Displays shortcut setup frame time.

MPC Initial Retry Time When the MPC does not receive a shortcut resolution

response, then it will wait for this initial retry time

before trying the resolution again.

MPC Retry Maximum Displays the limit on the amount of time that the

MPC will wait to get a shortcut resolution response.

MPC Hold Down Time Displays the minimum amount of time the MPC will

wait before re-initiating a failed shortcut resolution

attempt.

9.2.3 MPC Ingress and Egress Caches

To reach the MPC Ingress Cache View (see Figure 9.10) and the MPC Egress Cache View (see Figure 9.11) select the View MPC Ingress Cache option or the View MPC Egress Cache option, respectively, from the Manage MPOA menu (see Figure 9.1). These screens allow you to view the MPC Ingress and Egress Caches.

```
Ingress cache internetwork addr
essIngress cache destination address
Ingress cache prefix length
Ingress cache entry state
Ingress cache entry state
Ingress cache encap tag
Ingress cache encap tag
Ingress cache egress MPS address
Ingress Cache Retry Count
Ingress Cache Time Since Last Retry
Ingress cache hold time
Ingress cache transmitted packets

Quit First Next Previous Last Resample Switch =>
The I-Cache is empty.
```

Figure 9.10 - MPC Ingress Cache View

Ingress: Information travelling from the ES-3810 towards

ATM.

Internetwork Address Displays the IP address.

Prefix Length Displays the network portion of the IP address.

Entry State Displays a state which can be either resolved,

unresolved, or invalid. For instance, if a shortcut is set up for this destination, then the state is resolved.

Connection Index Displays information used for debugging.

Encap Tag Displays a cache tag for the Egress MPC, to be used

for sending packets over the shortcut.

Retry Count Displays the number of times resolution was

attempted.

Time Since Last Retry Displays the time elapsed since the last failed

resolution attempted.

Hold Time Displays the amount of time that Ingress cache entry

will remain valid.

Transmitted Packets Displays the number of transmitted packets.

```
ES-3810 View MPC Egress Cache

Rgress cache TD

Egress Cache Inetwork Addr Type

Egress cache destination address

Egress cache profix longth

Egress cache entry state

Egress cache encar tag

Eqress cache hold time

Egress cache data link header

Egress cache ingress MPC ATM addres

Rgress cache received packets

Quit First Next Previous Last Resample Switch ->

The E-Cache is empty.
```

Figure 9.11 - MPC Egress Cache View

Egress:	Information travelling from ATM into the ES-3810.		
Cache ID	Displays an identifier sent from Egress MPS to MPC.		
Destination Address	Displays the destination IP address of the traffic.		
Entry State	Displays either a resolved or unresolved entry state.		
Encap Tag	Displays the cache tag for the Ingress MPC to be used for sending packets over the shortcut.		
Hold Time	Displays the amount of time that Egress cache entry will remain valid.		
Data Link Header	Displays the DLL encapsulation that is used to forward packets.		
Received Packets	Displays the number of packets received.		

9.2.4 MPC MPS Table

To reach the MPC MPS Table (see Figure 9.12) select the View MPC MPS Table from the Manage MPOA menu. This screen allows you to view ATM and MAC addresses.




Figure 9.12 - MPC MPS Table View

mpcMPS ATM Address Displays the ATM address of the MPS that was

detected by the MPC.

mpcMPS MAC Address Displays the MAC address of the MPS.

9.2.5 MPOA Shortcut Routes

To view the MPOA Shortcut Routes view (see Figure 9.13) select the View MPC Shortcut Routes from the Manage MPOA menu (see Figure 9.1). This screen displays the shortcut routes.




Figure 9.13 - MPOA Shortcut Routes View

9.2.6 MPC Counter

To reach the MPC Counter view (see Figure 9.14) select the View MPC Counters option from the Manage MPOA menu (see Figure 9.1).

```
ES 3010 View MPC Counters
                                                                        4:50:00.60
    1) TxRslvReqs
                                      ) | 13) RxPurgeReqs
    2) KxRslvKeplyAcks
                                      ∃ 14) "xPurgeReplies
                                                                                 0
                                   O | 15) TXErrors
| | 16) RXErrUnreacgnizedExtensions
    3) KxKslvKeplyNackNcBindings
                                                                                 0
    4) RxRslvReplyNackNctTriques
                                                                                 11
    5) RxTmpReqs
                                      1 | 17) RxErrSubnetworkTDMismatchs
                                                                                 Π
    6) TxImpReplies
                                       3 | 18) RxErrLoopDetecteds
                                                                                 0
   7) TxEgressCacheFurgeReq
                                      3 | 19) RxErrProtoAddrUnreachablees
                                                                                 0
    8) RxEgressCacheFurgeReplies
                                      D | 20) RxErrProtoErrors
D | 21) RxErrSduSizoExcocdodo
                                                                                 0
    9) RxKcopAlivos
                                                                                 0
   10) ExTriggers
                                      3 22) RxErrInvalidExtensions
                                                                                 0
   11) RxDataPlanePurges
                                      3 23) RxRxErrAuthenticationFailures
                                                                                 0
   12) TxDataPlanePurges
                                       3 24) RxEirHopCounExceededs
                                                                                 0
Commands: +, -, Freeze, Unfreeze, Quit
```

Figure 9.14 - MPC Counter View

MPOA Management



ESM-16 Console Management Subsystem

The following details the menu selections available through the ESM-16 Console Management Subsystem. The ESM-16 Console Management Subsystem is not used in systems with an NMM or an NMC. If your system is configured with a either of these modules, please ignore this chapter and refer to Chapters 1 through 8.

The following sections detail the menu selections available through the ESM-16 Console Management Subsystem.

A.1 The Main Menu

The following is the main menu that will be displayed. This is the first menu displayed upon power up, as well as the menu that remains displayed after any menu selection is completed.

ForeRunner ES-3810 Copyright 1995 FORE Systems, Inc. Main Menu

- 1. View Port Configuration
- 2. View Port Counters
- 3. Set Port Configuration
- 4. Address Database Functions
- 5. Save Current Settings
- 6. Reset to Factory Default Settings
- 7. Download New Image
- 8. Initialize Port Counters
- 9. Reboot

Enter Selection:

A.1.1 View Port Configuration

The following menu is displayed for option 1 from the Main Menu.



The user will first be prompted for a port number to view.

ForeRunner ES-3810 Port Configuration

Please enter port number (1-16): 1 Firmware Version: V1.1.00 Hardware Version: 10B

Port implementation: SEC-10 Transmitter: **ENABLED** Chip number: Receive Buffer: **ENABLED Twisted Pair: ENABLED** Transmit Buffer: **ENABLED** Loopback: DISABLED Secure Learn: DISABLED **Sniff Segment:** DISABLED Receive Err Pkts: DISABLED **Full Duplex:** DISABLED Hash Uploading: DISABLED Force Transmit: DISABLED Flagged Packets: DISABLED **Polarity Correction:** Sniffed Packets: DISABLED DISABLED IA Promiscuous: DISABLED Link Detected: NO Link Polarity: OK MC Promiscuous: **ENABLED ENABLED** DISABLED Receiver: Backbone Mode:

Press ENTER to Return to Main Menu

A.1.2 View Port Counters

The following menu is displayed for Option 2 from the Main Menu.



The user will first be prompted for a port number to view.

ease enter port numbe	er (1-16): 1		
TRANSMITT	ER	RECEIVER	
Fotal Bytes:	1202010372	Total Bytes:	335294917
Packets:	2832049	Packets:	2293755
Lost Packets:	0	Lost Packets:	0
Broadcasts:	30862	Broadcasts:	69083
Multicasts:	175576	Multicasts:	69083
Single Collisions:	2299	Short Packets	0
Multiple Collisions:	2439	Long Packets:	0
Excessive Collisions:	0	Framing Errors:	0
NCL Packets:	0	FCS Error Packets:	0
Init Deferred Pkts:	113645	Late Collisions:	0

A.1.3 Set Port Configuration

The following menu is displayed for Option 3 from the Main Menu.



The user will first be prompted for a port number for which the parameters will be set. It is recommended that before any parameter is set to anything other than the Factory Default Setting, a thorough understanding of Section 8.2.1, Port Parameters, is required.

ForeRunner ES-3810 Set Port Attributes

The following attributes are settable:

- 1. Enable/Disable Loopback Mode
- 3. Enable/Disable Full Duplex Mode
- 5. Enable/Disable Transmitter
- 7. Enable/Disable Hash Upload
- 9. Enable/Disable Packet Sniffing
- 11. Enable/Disable MC Promiscuous Mode
- 13. Enable/Disable Receive Errors Mode
- 15. Enable/Disable Correct Polarity
- 17. Enable/Disable Rx Ring Buffer

- 2. Enable/Disable Segment Sniffing
- 4. Enable/Disable Receiver
- 6. Enable/Disable Secure Learning
- 8. Enable/Disable Flagged Packets
- 10. Enable/Disable IA Promiscuous Mode12. Enable/Disable Backbone Mode
- 14. Enable/Disable Twisted Pair Mode
- 16. Enable/Disable Force Tmit Mode
- 18. Enable/Disable Tx Ring Buffer

Please Enter Selection [range 1-18]:

For each of the parameters that may be set, the current state of the parameter is presented and the user is asked a final time if they are sure they want to change the parameter.

CAUTION



Any changes made are immediately implemented. Make sure you read Section 8.2.1 and have a thorough understanding of the port parameters.

A.1.4 Address Database Functions

Each port of the ES-3810 maintains an address database for the four addresses maintained for that port. These parameters can be either viewed or modified. Once the Address Database Functions option has been selected, a submenu is presented with three options - Option 1 allows the address aging time to be set, Option 2 allows address database viewing and Option 3 allows address database modifications.

ForeRunner ES-3810 Address Database Functions

- 1. Set Address Aging Time
- 2. View Address Database
- 3. Modify Address Database

Enter Selection:

A.1.4.1 Set Address Aging Time

By default, the ES-3810 will not automatically age idle addresses, that is, once learned, an address will stay within the respective ports address database until either a switch reboot or new addresses are learned by the port. The Set Address Aging Time option allows the network administrator to set a time limit on how long an idle address will reside within a ports address database before the firmware will age the address.

ForeRunner ES-3810 Set Address Aging Time

Please enter the Address Aging Time <0 - 59>: 20 Press ENTER to Return to Main Menu



The time entered is a global parameter. In the preceding example all addresses within all ports of the ES-3810 will age in 20 minutes if they are idle for that length of time.

A.1.4.2 View Address Database

The View Address Database option lets the contents of a port's address database to be displayed.

ForeRunner ES-3810 Address Database Functions				
Address	Flagged	Age Flag	Multicast Mask	Hash
00-A0-36-00-01-02	No	0	FFFF	No
00-A0-36-00-03-04	Yes	3	FFFF	No
00-A0-36-00-05-06	Yes	1	4	No
00-A0-36-00-07-08	No	2	В	No

A.1.4.3 Modify Address Database

The Modify Address Database Options allows for the modification of all the address database parameters.

	ForeRunner ES-3810			
	Modify Address	Databa	ase	
Address 1:	00-A0-36-00-01-02	Age:	3	
Address 2:	00-A0-36-00-03-04	Age:	0	
Address 3:	00-A0-36-00-05-06	Age:	1	
Address 4:	00-A0-36-00-07-08	Age:	2	
3. M 4. E Please Enter	n Individual Address (for Iulticast Domain (0h - Fh) nable/Disable Flag Bit Selection: 1 Address From Above (1-4 ge Information: 5		ddeeff)	
Enter New A				

A.1.5 Save Current Settings

The Save Current Settings option allows for any port parameter customization that has been performed to be saved in non-volatile storage. In this way, these parameter customizations are automatically restored upon an ES-3810 reboot or power cycle.

ForeRunner ES-3810 Save Current Settings

Saving Port Parameters
Press ENTER to Return to Main Menu

A.1.6 Reset to Factory Default Settings

The Reset to Factory Default option causes a full reset for each port of the ES-3810, resetting each ports entire parameter configuration to the default settings detailed in Section 3.4.1. When this option is selected, any customized settings that have been saved in non-volatile storage are cleared.

ForeRunner ES-3810 Reset to Factory Defaults

Resetting Port parameters Press ENTER to Return to Main Menu

A.1.7 Download New Image

The Download New Image option allows for firmware upgrades to be made to the *ForeRunner* ES-3810. The download option is built upon the XMODEM protocol; therefore, the management station must support the XMODEM protocol and must have the ability to load a software image onto a media device (e.g., hard disk, diskette).

The Download New Image option is a two-stage process - first, the option must be selected and second, the XMODEM protocol must be initiated. Once the option is selected, choose the binary transfer option from the XMODEM based application on the management station (e.g., Microsoft Windows 3.x Terminal). When prompted, enter the path where the file ES3810cm.BIN has been placed. The download takes approximately one minute to complete. Once the download finishes, the ES-3810 performs an automatic reboot.

ForeRunner ES-3810 Download New Image

Do you want to download a new image (Y/N)

Downloading Downloading Complete. Rebooting

A.1.8 Initialize Port Counters

The Initialize Port Counters option resets, on a port-by-port basis, the counters displayed (see Section 8.1.2) to all zeros.

ForeRunner ES-3810 Initialize Port Counters

Port Counter Initialization Complete. Press ENTER to Return to Main Menu

A.1.9 Reboot

The Reboot option performs a full initialization of the ES-3810. The power-up sequence detailed in Section 1.3 takes place.

ForeRunner ES-3810 Reboot

Are you sure you wish to reboot the ForeRunner ES-3810? <Y|N>

Rebooting

A.2 Port Characteristics

A.2.1 Port Parameters

The following section provides a brief description of each of the port's characteristics.

TwistedPairMode

When enabled, the port configures its transceivers as a standard twisted pair device. When disabled, the port configures the transceiver as an asynchronous NRZ interface designed to interface directly to a serial interface adapter.

LoopbackMode

When enabled, data sent by the transmitter is looped back to the receiver and all data from the receiver and collision input pins is ignored. When disabled, the port acts as a standard Ethernet CSMA/CD port.



The Loopback Mode is intended for diagnostic purposes only and should remain disabled.

SniffSegmentMode

When disabled, the port acts as a normal CSMA/CD port. When enabled, all packets sent by the transmitter are looped back to the receiver, but the receive and collision logic is not disabled. SniffSegmentMode forces all packets on a half-duplex port (sent and received) through the receiver to the Packet Bus allowing the segment to be "sniffed" elsewhere in the ES-3810.

FullDuplexMode

When disabled, each port acts as a 10 Mbit/sec CSMA/CD port. When enabled, the port acts as a 20 Mbit/sec port. Full Duplex mode indicates that send and receive can happen simultaneously.

ForceTransmissionMode

When disabled, the port acts as a standard 10 Mbit/sec CSMA/CD port. When enabled, packets are transmitted regardless of the state of the transceiver.



This parameter is for diagnostic purposes only and should remain disabled at all times.

CorrectPolarity Mode When enabled, data polarity can be corrected when the receiver is in an incorrect polarity mode. When disabled, data polarity correction logic is disabled.

LinkFailMode

This informational parameter indicates the status of the link integrity state. When OK, the port is operating properly; when Wrong, the link detection circuitry detected an error.

WrongPolarity Mode This informational parameter indicates the status of the polarity logic. When disabled, the received polarity of the packet is good. When enabled, the polarity is incorrect.

ReceiverMode

When enabled, the receiver portion of the Media Access Controller ("MAC") is active. When disabled, the receiver portion of the MAC is inactive.

ReceiveRingBufferMode

When enabled, the memory ring buffer used for packet reception is active. When disabled, the receive ring buffer becomes inactive.



ReceiverMode and ReceiveRing BufferMode must be enabled to receive packets on the port.

TransmitterMode

When enabled, the transmitter portion of the Media Access Controller ("MAC") is active. When disabled, the transmitter portion of the MAC is inactive.

TransmitterRing BufferMode When enabled, the memory ring buffer used for packet transmission is active. When disabled, the transmit ring buffer becomes inactive.



TransmitterMode and TransmitterRingBufferMode must be enabled to transmit packets on the port.

SecureLearnMode

When disabled, newly learned addresses are automatically used for forwarding from the Packet Bus to the Ethernet. When enabled, new addresses are stored in the address database but are only used for forwarding after the management processor confirms the validity of the newly learned address.



This feature is only available for in-band management configurations.

ReceiveErrorsMode

When enabled, all packets, including those with errors, are forwarded onto the Packet Bus. When disabled, received packets with errors are automatically deleted from the receive ring buffer memory and, therefore, are not forwarded on to the Packet Bus.

UploadMode

This parameter is reserved for future use.

FlaggedPacket Mode

When enabled, and none of the individual address flag bits are set, all packets with the flag bit set will be received from the Packet Bus and transmitted by the port. When enabled, and any of the individual address bits are set, packets with the flag bit set are received from the Packet Bus if the destination address matches one of the flagged addresses in the port's address database. When disabled, flagged packets are treated like any other packet on the Packet Bus.

SniffedPacket Mode

When enabled, all sniffed packets (transmitted or received) are taken from the Packet Bus and transmitted on the port. When disabled, sniffed transmit packets are ignored by this port and sniffed receive packets are handled like any other packet on the Packet Bus.

IndividualAddressPromiscuous Mode

When enabled, all individually addressed packets from the Packet Bus are transmitted by the port. When disabled, normal filtering is performed on individually addressed packets from the Packet Bus, such as matching the destination address with the addresses in the ports address database.

MulticastAddress PromiscuousMode

When enabled, all multicast messages from the Packet Bus are transmitted by the port. When disabled, normal filtering is performed on multicast messages from the Packet Bus.

BackboneMode

When enabled, the port transmits all individually addressed packets whose destination address does not reside in any of the ports' address databases.

When disabled, or in Workgroup Mode, normal operation is selected and only those individual addresses that match an entry in the ports' address database are received from the Packet Bus.



If all ports are in Workgroup Mode and a packet match does not occur within any port, the packet is simply dropped.

A.2.2 Address Databases

Each Workgroup port of an ES-3810 maintains a four-entry address database that is maintained in a dynamic fashion (i.e., addresses are learned, aged, and migrated in a dynamic, interactive nature). Additionally, each address database entry maintains certain characteristics about the address as follows:

Age Information

Each of the four addresses are numbered zero (0) through three (3) with zero being the most recently learned address and three being the oldest address in the database. Further, if an address was learned in SecureLearnMode, the age field is four (4) and the address is used for forwarding only after the management processor locks the address (which turns the age field to five (5) or acknowledges it (age=zero (0)). If an address has an age value of five (5), it will not be aged or migrated.

Hash Information

A one (1) in this field indicates a multicast hash table has been uploaded to the port from an end station.

Domain Information

This 16-bit field represents the virtual LAN, or multicast domain, information for the address. Each of the 16 bits represents a separate and unique virtual LAN/multicast domain to which this address can belong.

Index

A	C
AccessControlListViewandCommunitySelection	Client List View 6 - 4
6 - 4	Config Mode 9 - 17
access privileges	control 2 - 7
read/write privileges	controlling ATM addresses
changing password and username 1 - 3 changing usernames 1 - 4 default password 1 - 3 private 1 - 3 Address Database View 3 - 8, 3 - 17 ARP Cache View 5 - 4 Associating a VLAN to a Spanning Tree Instance 7 - 9 ATM uplink management menus AAL5 counters view 3 - 36 ATM counters view 3 - 35	Enable / Disable MPC option 9 - 10 controlling installed software 2 - 7 counter update exiting the screen 1 - 2 counter updates 1 - 2 commands 1 - 2 decreasing frequency of 1 - 2 freezing the screen 1 - 2 increasing frequency of 1 - 2 unfreezing the screen 1 - 2 Create RFC1483 Connection 3 - 28 Creating a Spanning Tree Instance 7 - 6
LANE counters view	D
LEC configuration view	default password
LEC VCC list view 3 - 25	Deleting a Spanning Tree Instance 7 - 14
manage interface menu 3 - 19	Disabling ILMI
manage LANE configuration menu 3 - 23 manage signaling configuration menu 3- 31 manageSONET/SDHconfigurationmenu 3 - 21	Displaying Spanning Tree Bridge Information 7 - 4 Displaying Spanning Tree Port Information 7 - 20 Displaying Spanning Tree Port Status 7 - 15
signaling configuration view 3 - 32	downloading a new software imag 2 - 8
signaling counters view 3 - 38	Downloading a New Software Image 2 - 8
SONET counters view 3 - 34	downloading a new software image 2 - 8
SONET/SDH configuration view . 3 - 22	dual ATM uplinks 3 - 19

E	Interface Management
Enabling and Disabling MPC	summary i
rejoining the ELAN 9 - 9	interface selection 3 - 1
Enabling ILMI 3 - 33	IP 5 - 10
Enabling MPCs on an ELAN 9 - 10	IP Counters 5 - 10
Enabling/ Disabling MPCs on an ELAN 9 - 10	IP Routing Table View 5 - 7
Enabling/Disabling Telne 8 - 3	L
Enabling/DisablingTrafficForwardingonaPort 7 - 22	last saved settings 1 - 1
ES-3810	LEC ARP Cache View
logon screen 1 - 4	LEC Configuration View 3 - 24
ES-3810 Main Menu 1 - 5	LEC sharing 3 - 19
ESM management menus	LEC VCC List
ESM address database view 3 - 8	local management console
ESM interface configuration view . 3 - 6	main functions 1 - 1
ESM interface counters view 3 - 10	local management menus address database functionsA - 5
ESM manage address database menu 3- 7	download new image A - 7
ESMmanageinterfaceconfigurationmenu	initialize port counters A - 8
3 - 3	main menu
ESM manage interface menu 3 - 2	modify address database A - 6
ESM modify address database menu 3-9	port characteristics
ESM-16 Console Management Subsystem	address databases A - 12
summary i	port parameters
ESM-16 management module	reboot
with NMM installed 1 - 1	reset to factory default settings \dots A - 7
F	save current settings
factory default settings	set address aging time
FEM management menus	set port configuration
FEM interface configuration view 3 - 15	view address database A - 6
FEM manage configuration menu 3 - 12	view port configuration
FEM manage interface menu 3 - 11	view port counters A - 3
	logging off
<u> </u>	logging on
ICMP Counters	M
Initial Retry Time	Main Menu
Initial Retry Time view 9 - 13	Logoff 1 - 6
Interface Configuration View 3 - 6 3 - 15	

Manage Interface 1 - 5	Manage MPC Configuration 9 - 7
Manage MPOA 1 - 6	Select Another ELAN 9 - 7
Manage SNMP 1 - 6	View MPC counters 9 - 7
Manage Spanning Tree 1 - 6	View MPC Egress Cache 9 - 7
Manage System 1 - 5	View MPC Ingress Cache 9 - 7
Manage Telnet 1 - 6	View MPC MPS Table 9 - 7
Manage UDP/IP1 - 6	View MPC Status 9 - 7
Manage VLAN 1 - 6	View MPOA Shortcut Routes 9 - 7
Reset Counters 1 - 6	Manage RFC1483 Connection 3 - 26
Manage Access Control List Menu 6 - 2	Manage Signaling Configuration Men 3 - 30
Manage Address Database Menu . 3 - 7, 3 - 16	Manage SNMP Menu 6 - 1
Manage ARP Cache Menu 5 - 2	Manage Software Menu2 - 7
Manage ATM Interface Menu 3 - 19	Download Software 2 - 7
Manage Configuration Menu 3 - 12	Select Another Software Module 2 - 7
Manage ILMI Configuration 3 - 32	View Software Invent 2 - 7
Manage Interface Configuration Menu 3 - 3	Manage SONET/SDH Configuration Menu 3-
Manage Interface Menu	20
Manage IP Parameters Menu 5 - 4	Manage Spanning Tree Menu 7 - 3
Manage IP Routing Table Menu 5 - 5	Manage System Menu 2 - 1
Manage LANE Configuration Menu 3 - 23	Manage Module 2 - 1
Manage Module Menu 2 - 4	Manage Software 2 - 1
Reset Module 2 - 4	Manage System Parameters 2 - 1
Select Another Module 2 - 4	Reboot System 2 - 2
Test Module 2 - 5	Restore Factory Default Configuration 2-
View Module 2 - 4	2
View Module Inventory 2 - 5	Restore Last Saved Configuration . 2 - 2
Manage MPC Configuration Menu 9 - 8	Save Current Configuration 2 - 2
Config Mode 9 - 8	Manage System Parameters Menu 2 - 2
Configuration Mask 9 - 8	Manage Trap Destination List Menu 6 - 5
Control/ Data ATM address 9 - 8	Manage UDP/IP Menu 5 - 1
Enable / Disable MPC 9 - 8	Manage VLAN Menu 4 - 1
Hold Down Time 9 - 9	Managing 10 Mbps Ethernet Interfaces 3 - 2
Initial Retry Time 9 - 9	Managing 10/100Base Ethernet Interfaces 3-11
Retry Maximum 9 - 9	Managing ATM Interfaces 3 - 19
Shortcut Setup Frame Count 9 - 8	managing objects, system-wide 2 - 1
Shortcut Setup Frame Time 9 - 8	Managing Spanning Tree Port Configuration 7
Manage MPOA Menu 9 - 7	- 18
	managing telnet8 - 1

menu system	manual mode 9 - 9
general 1 - 1	MPOA parameters 9 - 9
modifications to equipmentv	Retry Maximum9 - 9, 9 - 14
Modify Address Database Menu 3 - 9, 3 - 17	Shortcut Setup Frame Count 9 - 8
Modify IP Routing Entry Menu 5 - 7	Shortcut Setup Frame Time 9 - 8
Modify VLAN Menu 4 - 2	MPC configuration mode 9 - 9
Modifying Spanning Tree Bridge Forward Delay	MPC hold down time 9 - 17
7 - 13	MPC Ingress Cache View 9 - 18
Modifying Spanning Tree Bridge Hello Time 7	MPC initial retry time 9 - 17
- 12	MPC MPS Table 9 - 21
Modifying Spanning Tree Bridge Information 7	MPC retry maximum 9 - 17
- 8	MPC shortcut setup frame count 9 - 17
ModifyingSpanningTreeBridgeMaximumAge 7 - 11	MPC shortcut setup frame time 9 - 17
Modifying Spanning Tree Bridge Priority 7 - 10	MPC state 9 - 17
Modifying STP Port Path Cost	MPC Status View 9 - 16
Modifying STP Port Priority 7 - 23	MPC Status view
Modifying the Timeout Value 8 - 4	Config Mode 9 - 17
Module Inventory View	MPC Actual Auth Type 9 - 17
Module Selection Menu	MPC Actual Control ATM Address 9 - 17
Module Selection screen	MPC Actual Data ATM Address . 9 - 17
monitoring installed software 2 - 7	MPC Hold Down Time 9 - 17
MPC	MPC Initial Retry Time 9 - 17
enabling and disabling 9 - 9	MPC Retry Maximum 9 - 17
switching states	MPC Shortcut Setup Frame Count 9 - 17
automatic 9 - 9	MPC Shortcut Setup Frame Time . 9 - 17
manual	MPC State 9 - 17
MPC actual authentication type 9 - 17	MPOA 9 - 9
MPC actual control ATM address 9 - 17	MPOA Management
MPC actual data ATM address 9 - 17	summary
MPC configuration	MPOA parameters
automatic 9 - 9	LECS 9 - 9
Config Mode	locally assigned defaults 9 - 9
Configuration Mask 9 - 8	N
Control/ Data ATM address 9 - 8	Network Management Controller 1 - 1
Enable / Disable MPC 9 - 8	Network Management Module 1 - 1
Hold Down Time 9 - 9	NMC
Initial Retry Time9 - 9, 9 - 13	NMM
induited y 11116 3 - 0, 3 - 10	1 414114 1 - 1

primary functions 1 - 1	SNMP Management
P	summary i
passwords	SNMP-based management 1 - 1
changing of1 - 3	Software Inventory View 2 - 8
Ping	Software Selection Menu 2 - 8
power cord connectionv	SONET/SDH Configuration View 3 - 22
power-up diagnostics	spanning tree
power-up diagnostics	ES-3810 implementation $\dots 7$ - 2
private	overview 7 - 1
default password	Spanning Tree Management
product placementv	summary i
product pracementv	spanning tree management
R	associate VLANS 7 - 9
read/write privileges	bridge information display7 - 4, 9 - 18
changing of	create spanning tree7 - 6, 9 - 21
redundant ATM uplinks 3 - 19	delete spanning tree 7 - 14
resetting counters 1 - 6	enable/disable traffic forwarding . 7 - 22
Resetting Interface Counters 3 - 10, 3 - 18	manage spanning tree 7 - 3, 9 - 8
Resetting the Interface 3 - 3, 3 - 12	modify bridge configuration .7 - 8, 9 - 23
Retry Maximum 9 - 14	modify bridge priority 7 - 10
Retry Maximum view 9 - 14	modify forward delay 7 - 13
s	modify hello time 7 - 12
safety precautionsiv	modify max age 7 - 11
Select Another ELAN 9 - 7	modify port configuration 7 - 18
selecting a module	modify port path cost 7 - 24
Selecting a Spanning Tree Instance 7 - 4	modify port priority 7 - 23
Selecting a Spanning Tree Port 7 - 19	port information 7 - 20
selecting an interface	port status view 7 - 15
selecting installed software 2 - 8	select port 7 - 19
setting up shortcut VCs	select spanning tree 7 - 4, 9 - 16
shortcut frame count 9 - 12	switch STP OFF 7 - 17
shortcut frame time 9 - 11	switch STP ON 7 - 16
Shortcut Setup Frame Count 9 - 11	toggle STP 7 - 21
Shortcut Setup Frame Count view 9 - 11	Switching-off STP on Ports 7 - 17
Shortcut Setup Frame Time view 9 - 12	Switching-on STP on Ports 7 - 16
Signaling Configuration View 3 - 32	System Management
SNMP Counters 6 - 7	summary i

system management menus	Telnet Management
access control list view 6 - 4	Overview 8 - 1
ARP cache view 5 - 4	summary i
client list view 6 - 4	TFTP read utility 2 - 7
IP routing table view 5 - 7	Toggling STP on a Port 7 - 21
manage access control list menu 6 - 2	typographical stylesiii
manage ARP cache menu 5 - 2	U
manage IP parameters menu 5 - 5	UDP Counters 5 - 11
manage IP routing table menu 5 - 6	UDP/IP Management
manage module menu 2 - 4	summaryi
manage SNMP menu 6 - 1	user interface 1 - 2
manage software menu 2 - 7	console text display problems 1 - 2
manage system menu 2 - 1	main menu
manage system parameters 2 - 2	system management 2 - 1
manage trap destination list menu . 6 - 5	usernames
manage UDP/IP menu 5 - 1	changing of 1 - 3, 1 - 4
manage VLAN menu 4 - 1	private
modify VLAN menu 4 - 2	public 1 - 3
module inventory view 2 - 6	•
module selection menu 2 - 5	V
system parameters view 2 - 3	View AAL5 Counters 3 - 36
UDP counters view 5 - 11	View ATM Counters
view ICMP counters 5 - 9	View LANE Counters 3 - 37
view IP counters 5 - 10	View LEC Counters
view SNMP counters 6 - 7	View RFC1483 Connection 3 - 27
view trap destination list 6 - 6	View Signaling Counters 3 - 38
VLAN inventory view 4 - 4	View SONET Counters 3 - 34
VLAN selection menu 4 - 3	View System Parameters 2 - 3
VLAN view 4 - 4	View Trap Destination List 6 - 6
т	Viewing Interface Counters3 - 10, 3 - 18
	Viewing TCP Connections 8 - 5
Technical Supportii telnet	Viewing Telnet Parameters 8 - 2
	VLAN Inventory View 4 - 4
disabling 8 - 3	VLAN Management
enabling 8 - 3	summary i
managing 8 - 1	VLAN Selection Menu 4 - 3
timeout modification 8 - 4	VLAN View 4 - 4
viewing settings 8 - 2	

VT-100 terminal	1	-	1
VT-100 terminal emulator	1	_	1

Index